



**Owner's Manual for the Vehicle.
With a quick reference guide
for your convenience.**



323i
328i

Congratulations, and thank you for choosing a BMW.

Thorough familiarity with your vehicle will provide you with enhanced control and security when you drive it. We therefore have this request:

Please take the time to read this Owner's Manual and familiarize yourself with the information that we have compiled for you before driving your new car. It contains important data and instructions intended to assist you in gaining maximum use and satisfaction from the unique range of technical features on your BMW. The manual also contains information on care and maintenance designed to enhance operating safety and contribute to maintaining the value of your BMW throughout an extended service life.

This Owner's Manual should be considered a permanent part of this vehicle. It should stay with the vehicle when sold to provide the next owner with important operating, safety and maintenance information.

This manual is supplemented by a Service and Warranty Information Booklet (US models) or a Warranty and Service Guide Booklet (Canadian models). We recommend that you read these publications thoroughly.

Your BMW is covered by the following warranties:

- New Vehicle Limited Warranty
- Limited Warranty Rust Perforation
- Emissions System Defect Warranty
- Emissions Performance Warranty
- California Emissions Control System Limited Warranty

Detailed information about these warranties is listed in the Service and Warranty Information Booklet (US models) and the Warranty and Service Guide Booklet (Canadian models).

We wish you an enjoyable driving experience.

BMW AG

Notes on the Owner's Manual

We have made every effort to ensure that you are able to find what you need in this Owner's Manual as quickly as possible. The fastest way to find certain topics is by using the detailed index at the end. If you wish to gain only an initial overview of your vehicle, you will find this in the first chapter.

The detailed list of contents that directly follows the summary of contents is intended to stimulate your curiosity regarding your BMW and to encourage you to read the manual.

Should you wish to sell your BMW at some time in the future, please remember to hand over this Owner's Manual to the new owner; it is part of the vehicle.

Should you have any further questions, your BMW center will be glad to assist at any time.

© 1999 BMW AG
Munich, Germany
Reprinting, including excerpts, only with the written consent of BMW AG, Munich.
Order number 01 41 0 155 024
US English IX/99
Printed in Germany
Printed on environmentally friendly paper
(bleached without chlorine, suitable for recycling)

Symbols used



These sections contain vital information – please read the accompanying text passages carefully, for your safety, the safety of others and to prevent damage to your BMW. ◀



These passages contain information on special and unique features of your vehicle. ◀



Indicates special information on recycling. ◀

◀ Indicates the end of a note.

* Indicates special equipment, country-specific equipment and optional extras.



Indicates that you should consult the relevant section of this Owner's Manual for information on a specific part or assembly.



Alerts you to functions that can be adjusted by your BMW center ("Car Memory" or "Key Memory"). Refer to page 53. ◀

The individual vehicle

On purchasing your BMW, you have decided in favor of a model with individualized equipment and features. This Owner's Manual describes all models and equipment that BMW offers within the same group.

We hope you will understand that equipment and features are included which you might not have chosen for your vehicle. Any differences can easily be identified, since all optional accessories and special equipment are marked with an asterisk *.

If your BMW features equipment which is not described in this Owner's Manual (car radio or telephone, for instance), Supplementary Owner's Manuals are enclosed. We ask you to read these manuals as well.

Status at time of printing

BMW pursues a policy of continuous, ongoing development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards combined with advanced, state-of-the-art technology. For this reason, it is possible that the features described in this Owner's Manual could differ from those on your vehicle. Nor can errors and omissions be entirely ruled out. You are therefore asked to appreciate that no legal claims can be entertained on the basis of the data, illustrations or descriptions in this Owner's Manual.

For your own safety



Use unleaded gasoline only. Fuels containing up to 10% ethanol or other oxygenates with up to 2.8% oxygen by weight (i.e. 15% MTBE or 3% methanol plus an equivalent amount of co-solvent) will not void the applicable warranties with respect to defects in materials or workmanship. Field experience has indicated significant differences in fuel quality (volatility, composition, additives, for example) among gasolines offered for sale in the United States and Canada. The use of poor-quality fuels may result in driveability, starting and stalling problems, especially under certain environmental conditions, such as high ambient temperature and high altitude. Should you encounter driveability problems that you suspect could be related to the fuel you are using, we recommend that you respond by switching to a recognized high-quality brand. Failure to comply with these recommendations may result in unscheduled maintenance. Follow the relevant safety rules when you are handling gasoline. ◀



Important safety information! For your own safety, use genuine parts and accessories approved by BMW. When you purchase accessories tested and approved by BMW and Original BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle. BMW warrants these parts to be free from defects in material and workmanship. BMW will not accept any liability for damage resulting from installation of parts and accessories not approved by BMW. BMW cannot test every product from other manufacturers to verify if it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants. Original BMW Parts, BMW Accessories and other products approved by BMW, together with professional advice on using these items, are available from all BMW centers.

Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones (including operation of any portable cellular phone from within the vehicle without using an externally mounted antenna) or transceiver equipment (such as C.B., walkie-talkie, ham radio or similar) may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. See your BMW center for additional information.

Do not use a key or remote control to lock the doors or luggage compartment with anyone inside the car. See page 34 for more details. "Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part." ◀

The following only applies to vehicles owned and operated in the US.

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect that could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying BMW of North America, Inc., P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone (201) 307-4000.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, Inc.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 202-366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, DC 20590. You can also obtain other information about motor vehicle safety from the Hotline.



Overview

Controls and features

Operation, care
and maintenance

Owner service procedures

Advanced technology

Technical data

Index



Contents

Overview

- Cockpit 16
- Instrument cluster 18
- Indicator and warning lamps 20
- Multifunction steering wheel (MFL) 24
- Hazard warning flashers 25
- Warning triangle 25
- First-aid kit 25
- Refueling 26
- Fuel specifications 26
- Tire inflation pressure 27

Controls and features

- Locks and security systems:**
 - Keys 32
 - Electronic vehicle immobilizer 33
 - Central locking system 34
 - Opening and closing – from outside 34
 - Opening and closing – from inside 38
 - Luggage compartment lid 39
 - Luggage compartment 41
 - Alarm system 42
 - Electric power windows 44
 - Sliding/Tilt sunroof 45

Adjustments:

- Seats 47
- Seat and mirror memory 50
- Steering wheel 51
- Mirrors 52
- Car Memory, Key Memory 53

Passenger safety systems:

- Safety belts 54
- Child restraint systems 55
- Child-safety locks 56
- Airbags 56
- Child restraints 59
- Installing a child restraint system 60

Driving:

- Steering/Ignition lock 61
- Starting the engine 61
- Switching off the engine 62
- Parking brake 63
- Manual transmission 64
- Automatic transmission with Steptronic 65
- Turn signal indicator/Headlamp flasher 68
- Wiper/Washer system/Rain sensor 68
- Rear window defroster 70
- Cruise control 71

Everything under control:

- Odometer 73
- Tachometer 73
- Energy Control 73
- Fuel gauge 74
- Temperature gauge 74
- Service Interval Display 74
- Check Control 75
- Clock 75
- Onboard computer 76

Technology for safety and convenience:

- Park Distance Control (PDC) 78
- Dynamic Stability Control (DSC) 79
- Tire Pressure Control (RDC) 80

- Controls and features**
- Lamps:**
 - Parking lamps/Headlamps 82
 - Dash lighting 82
 - High beams/Parking lamps 83
 - Fog lamps 83
 - Interior lamps 83
 - Reading lamps 84
 - Controlling the climate for pleasant driving:**
 - Automatic climate control 86
 - Seat heating 91
 - Roller sun blind 91
 - Interior conveniences:**
 - HiFi system 92
 - Glove compartment 92
 - Storage compartments 93
 - Cellular phones 95
 - Ashtray, front 95
 - Cigarette lighter 96
 - Ashtray, rear 96
 - Loading and transporting:**
 - Through-loading system 97
 - Ski bag 98
 - Cargo loading 99
 - Roof-mounted luggage rack 100
- Operation, care and maintenance**
- Special operating instructions:**
 - Break-in procedures 104
 - Driving notes 104
 - Catalytic converter 105
 - Antilock Brake System (ABS) 106
 - Disc brakes 108
 - Brake system 109
 - Winter operation 110
 - Power steering 111
 - Cellular phones 112
 - Radio reception 112
 - Wheels and tires:**
 - Tire inflation pressures 113
 - Tire condition 113
 - Tire replacement 114
 - Tire rotation 115
 - Wheel and tire combinations 116
 - Winter tires 117
 - Snow chains 117
 - Approved wheel and tire specifications 118
 - Under the hood:**
 - Hood 120
 - Engine compartment 122
 - Washer fluids 124
 - Washer nozzles 124
 - Engine oil 125
 - Coolant 128
 - Brake fluid 129
 - Vehicle Identification Number 130
 - Care and maintenance:**
 - The BMW Maintenance System 131
 - Caring for your car 132
 - Airbags 137
 - Vehicle storage 137
 - Laws and regulations:**
 - Technical modifications to the vehicle 138
 - OBD interface socket 139

Contents

Owner service procedures

Replacement procedures:

- Onboard tool kit [142](#)
- Windshield wiper blades [142](#)
- Lamps and bulbs [142](#)
- Changing a wheel [149](#)
- Battery [152](#)
- Fuses [154](#)
- Microfilter [155](#)

In case of electrical malfunction:

- Fuel filler door [156](#)
- Sliding/Tilt sunroof [156](#)

Assistance, giving and receiving:

- Jump-starting [157](#)
- Towing the vehicle [158](#)

Advanced technology

- Adaptive Transmission Control (ATC) [162](#)
- Airbags [163](#)
- Dynamic Stability Control (DSC) [163](#)
- Radio reception [164](#)
- Safety belt tensioner [164](#)
- Interior rearview mirror with automatic dimming feature [165](#)
- Rain sensor [166](#)
- Tire Pressure Control (RDC) [167](#)
- Self-diagnostics [168](#)
- Xenon lamps [169](#)

Technical data


- Engine data [172](#)
- Dimensions [173](#)
- Weights [174](#)
- Capacities [175](#)
- Electrical system [176](#)
- Ribbed V-belt [176](#)

Index

- Everything from A to Z [180](#)
- Owner service procedures [186](#)



Cockpit 16
 Instrument cluster 18
 Indicator and warning lamps 20
 Multifunction steering wheel
 (MFL) 24
 Hazard warning flashers 25
 Warning triangle 25
 First-aid kit 25
 Refueling 26
 Fuel specifications 26
 Tire inflation pressure 27



Overview

Controls and features

Operation, care and maintenance


Owner service procedures

Advanced technology

Technical data

Index

16 Cockpit



- 1 Headlamp switch [82](#)
- 2 ▷ Turn signal indicator [68](#)
 - ▷ Parking lamps [83](#)
 - ▷ High beams [83](#)
 - ▷ Headlamp flasher [68](#)
 - ▷ Onboard computer* [76](#)
- 3 Wiper/Washer system [68](#)
- 4 Shift lever/Selector lever* [64](#)

For vehicles equipped with manual transmission:
Press the lever to the left to overcome the slight resistance to engage reverse gear
- 5 Central locking system [34](#)
- 6 Hazard warning flashers [25](#)
- 7 Rear window defroster [70](#)
- 8 Horn: The entire surface functions as the horn
- 9 Adjusting steering wheel [51](#)
- 10 Front fog lamps* [83](#)

18 Instrument cluster



Instrument cluster

- 1 Fuel gauge with indicator lamp for fuel reserve [74](#)
- 2 Turn signal indicator [23](#)
- 3 Speedometer
- 4 Indicator lamp for
 - ▷ Battery charge current [20](#)
 - ▷ High beams [23](#)
 - ▷ Engine oil pressure/Engine oil level [20](#), [22](#)
- 5 Tachometer and Energy Control [73](#)
- 6 Engine coolant temperature gauge with "Coolant temperature too high" indicator [74](#)
- 7 Indicator and warning lamps (clockwise) for
 - ▷ Parking brake/Brake hydraulic system/Cornering Brake Control (CBC) [20](#)
 - ▷ ABS [22](#)
 - ▷ Brake pads [22](#)
 - ▷ Tire Pressure Control (RDC)* [20](#), [22](#)
 - ▷ Airbags [21](#)
 - ▷ Please fasten safety belts [21](#)
 - ▷ Cruise control* [23](#)
- 8 Clock reset
 - ▷ Clock [75](#)
 - ▷ Service Interval [74](#)
- 9 Program display for automatic transmission* [65](#), [67](#)
Indicator lamp for automatic transmission* [22](#), [65](#)
- 10 Indicator lamp for Dynamic Stability Control (DSC) [22](#)
- 11 Indicator for
 - ▷ Odometer [73](#)
 - ▷ Trip odometer [73](#)
 - ▷ Clock [75](#)
 - ▷ Service Interval [74](#)

Display for onboard computer*, operation via the turn signal lever: Refer to page [76](#).

 - ▷ Clock
 - ▷ Outside temperature
 - ▷ Average fuel consumption
 - ▷ Range
 - ▷ Average speed
- 12 Indicator for Check Control [75](#)
- 13 Trip odometer, reset to zero [73](#)
- 14 Indicator and warning lamps (clockwise) for
 - ▷ Front fog lamps* [23](#)
 - ▷ Add washer fluid [22](#)
 - ▷ Coolant level [23](#)
 - ▷ Electronic Engine Power Control (EML)* [23](#)
 - ▷ Engine [22](#)



You can display the outside temperature and distance driven in different units of measurement. ◀

Technology that monitors itself

Many of the systems of your BMW monitor themselves automatically, both during engine starts and while you are driving. Indicator and warning lamps that are identified by "●" are tested for proper functioning whenever the ignition key is turned. They each light up once for different periods of time.

If a fault should occur in one of these systems, the corresponding lamp does not go out after the engine is started, or it lights up while the vehicle is moving. You will see how to react to this below.

Red: Stop immediately



Battery charge ●

The battery is no longer being charged. There is a malfunction of the alternator ribbed V-belt or in the charging circuit of the alternator. Please contact the nearest BMW center.



If the ribbed V-belt is defective, do not continue driving. If you do so, the engine could be damaged due to overheating. If the ribbed V-belt is defective, increased steering effort is also required. ◀



Engine oil pressure ●

Stop the vehicle and switch off the engine immediately. Check the engine oil and top up as required. If the oil level is correct, please contact the nearest BMW center.



Do not continue driving. If you do so, the engine could be damaged because of inadequate lubrication. ◀



Tire Pressure Control (RDC)* ●

In addition, an acoustic signal is sounded: A tire failure has occurred. Reduce vehicle speed immediately and stop the vehicle. Avoid hard brake applications. Do not oversteer. For additional information: Refer to page 80.



Brake hydraulic system ●

If the lamp comes on when the parking brake is not engaged: Check the brake fluid level. Before driving further, be sure to read the notes on pages 109 and 129.



Brake warning lamp for Canadian models.

Indicator and warning lamps

Yellow: Stop immediately



Engine oil level

Comes on while driving: Stop the vehicle and switch off the engine immediately. The oil level is at the absolute minimum.

For additional information: Refer to page [125](#).



Do not continue driving until you have topped up the engine oil. If you continue to drive, the engine could be damaged because of inadequate lubrication. ◀

Red and yellow: Continue driving cautiously



Cornering Brake Control (CBC) ●
If the brake warning lamp comes on together with the yellow indicator lamps for ABS and DSC: The entire ABS, CBC and DSC control system has failed. Continue driving cautiously and defensively. Avoid hard brake applications. Please have the system checked by your BMW center as soon as possible.

For additional information: Refer to pages [79](#) and [107](#).



CBC, ABS and DSC indicator and warning lamps for Canadian models.

Red: An important reminder



Parking brake

Comes on when the parking brake is applied – an additional acoustic signal sounds when starting off.

For additional information: Refer to page [63](#).



Brake warning lamp for Canadian models.



Please fasten safety belts ●
An acoustic warning signal sounds simultaneously. Lights up for a few seconds or until the safety belt is fastened.

For additional information on safety belts: Refer to page [54](#).



Airbags ●

Please have the system inspected by your BMW center.

For additional information: Refer to pages [56](#) and [163](#).

22 Indicator and warning lamps

Orange: Consult the nearest BMW center



Automatic transmission*
Because of a malfunction, the automatic transmission shifts only in the emergency program. Please consult the nearest BMW center. For additional information: Refer to page [65](#).

Yellow: Check as soon as possible



Antilock Brake System (ABS) ●
ABS has been deactivated in response to system malfunction. Conventional braking efficiency is available without limitations. Please have the system inspected by your BMW center.

For additional information: Refer to page [107](#).



ABS warning lamp for Canadian models.



Engine oil level
Comes on after the engine has been turned off: Check the engine oil level. For additional information: Refer to page [125](#).



Brake pads ●
Have the brake pads checked. For additional information: Refer to page [109](#).



Tire Pressure Control (RDC)* ●
Check the tire pressure. Refer to pages [27](#) and [80](#).



Dynamic Stability Control (DSC) ●
DSC has been switched off or has been deactivated because of a malfunction. In the event of a malfunction, have the system checked by your BMW center.

For additional information: Refer to page [79](#).



Add washer fluid
The washer fluid is too low. Top off the fluid at the earliest opportunity. For additional information: Refer to page [124](#).



Service engine soon ●
There is a defect in the Engine Management system. It is important to note that an illuminated lamp is intended to inform the driver of the need for service, not of the need to stop the vehicle.

This can also be an indication that the filler cap was not properly tightened after refueling. Please have the system inspected by your BMW center. For additional information: Refer to page [139](#).



Engine Management warning lamp for Canadian models.

Indicator and warning lamps



Electronic Engine Power Control (EML)* ●

Malfunction in engine timing. Higher brake application pressure may be necessary and brake pedal travel may be significantly longer. Please have the system inspected by your BMW center.



Add coolant

The coolant level is too low. Top up the coolant at the earliest opportunity.

For additional information: Refer to page [128](#).

Green: For your information



Turn signal indicator

Flashes when the turn signal indicator is actuated. Includes the trailer turn signals if you are towing a trailer. Rapid flashing indicates a system malfunction.

For additional information: Refer to page [68](#).



Cruise control*

Comes on when the cruise control is activated. Available for operation via the multifunction steering wheel.

For additional information: Refer to page [71](#).



Front fog lamps*

Lights up whenever you switch on the front fog lamps.

For additional information: Refer to page [83](#).

Blue: For your information



High beams

Lights up when the high beams are on or the headlamp flasher is actuated.

For additional information: Refer to pages [68](#) and [83](#).

24 Multifunction steering wheel (MFL)*

The controls integrated in the multifunction steering wheel are provided so that you can operate a number of accessories quickly and without being distracted from traffic conditions. You may operate:

- ▷ selected radio functions
- ▷ the cruise control
- ▷ selected cellular phone functions.



In order to operate a system via the MFL, the corresponding system controls must be switched on. ◀



- | | |
|--|--|
| 1 Cellular phone: Receive a call, initiate dialing and terminate a call | 6 Horn: The entire surface functions as the horn |
| 2 Radio/Cellular phone: Select | 7 Cruise control: Resume stored setting |
| 3 Radio/Cellular phone: Scan backward or scan station keys or scroll in the phone listings | 8 Cruise control: Store and accelerate (+); decelerate and store (-) |
| 4 Radio/Cellular phone: Volume | 9 Cruise control: Activate/Interrupt/Cancel. |
| 5 Radio/Cellular phone: Scan forward or scan station keys or scroll in the phone listings | |

Hazard warning flashers




The push button flashes rhythmically when the hazard flashers are on. To help you locate the switch in an emergency, the button is also illuminated whenever the car lamps are on.

Warning triangle*



The hazard warning triangle is stored in a recess on the left-hand side of the luggage compartment where it is quickly available.

 Comply with legal requirements that cover the availability of a hazard warning triangle in the car. ◀


First-aid kit*



The first-aid kit is located under the passenger seat.

To open: Pull the handle and fold the cover down.

To close: Fold the cover up.


 Some of the articles in the first-aid kit may be used within a limited time only. For this reason, check the expiration dates of each of the items regularly, and replace any whose expiration dates have passed. You can purchase replacements in any drugstore or pharmacy. Comply with legal requirements that cover the availability of a first-aid kit in the car. ◀



Fuel filler door


Press on the rear edge of the fuel filler door to open and close it.

To unlock the fuel filler door if there is a malfunction of the central locking system, refer to page [156](#).

 When handling fuels, comply with all of the applicable safety precautions and regulations pertaining to fuels. Never carry spare fuel containers in your vehicle. Whether empty or full, these containers can leak, cause an explosion, or lead to fire in the event of a collision. ◀




Simple and environmentally friendly

 Open the fuel filler cap carefully. If you do not, fuel could spray out. Fuel spray may cause injury. ◀

Keep the filler cap in the bracket attached to the fuel filler door.

When refueling, insert the filler nozzle completely into the filler pipe. Pulling the nozzle out of the pipe during refueling

- ▷ results in premature pump shutoff
- ▷ and will reduce the effect of the vapor recovery system on the pump.

 Close the fuel cap carefully after refueling. A loose or missing cap will activate the Service Engine Soon warning lamp. ◀


Fuel specifications

Use unleaded gasoline only.

Recommended fuel: Premium with a minimum octane rating of 91 AKI.

BMW engines are equipped with knock sensors and will adapt automatically to different octane ratings, provided that the minimum octane requirement (87 AKI) is met.

Fuels with higher octane ratings will provide enhanced performance and lower fuel consumption, while the use of fuels with lower octane ratings will have the opposite effect.

 Do not use leaded fuels. The use of leaded fuels will cause permanent damage to the system's oxygen sensor and the catalytic convertor. ◀

AKI = Anti Knock Index

Tire inflation pressure



The inflation pressures are indicated on a sticker attached to the door pillar behind the driver's door (visible with door open).

Check tire pressures

All pressure specifications are stated in psi (kilopascal) with cold tires (cold = ambient temperature). Refer to the next page as well.

For vehicles with RDC (Tire Pressure Control)*:

After a correction of the tire inflation pressure, reactivate the system. Refer to page [80](#).



Check tire inflation pressures regularly – at least every two weeks and before beginning a longer trip. Incorrect tire pressure can otherwise lead to tire damage and accidents. Also check the inflation pressure of the space-saver tire or spare tire*. Inflate the spare tire to the highest inflation specified for your vehicle. ◀

Comply with tire approval specifications

The inflation pressures in the table apply to tires from BMW-approved manufacturers. Your BMW center is familiar with these pressures. Higher pressures may be specified for tires from other manufacturers. You will find a list of approved tires beginning on page [118](#).

28 Tire inflation pressure

| BMW | Tires | Inflation pressures in psi (kilopascal) | | | |
|------|------------------------|---|----------|----------|----------|
| | | | | | |
| 323i | Summer tires | 29 (2.0) | 33 (2.3) | 33 (2.3) | 41 (2.8) |
| | Winter tires | 32 (2.2) | 36 (2.5) | 36 (2.5) | 44 (3.0) |
| 328i | Summer tires | 29 (2.0) | 33 (2.3) | 33 (2.3) | 41 (2.8) |
| | Winter tires | 32 (2.2) | 36 (2.5) | 36 (2.5) | 44 (3.0) |
| All | Space-saver spare tire | 61 (4.2) | 61 (4.2) | 61 (4.2) | 61 (4.2) |

For all-season tires, use the same tire inflation pressure as for summer tires.

Locks and security systems:

Keys 32

Electronic vehicle

immobilizer 33

Central locking system 34

Opening and closing – from
outside 34Opening and closing – from
inside 38

Luggage compartment lid 39

Luggage compartment 41

Alarm system 42

Electric power windows 44

Sliding/Tilt sunroof 45

Adjustments:

Seats 47

Seat and mirror memory 50

Steering wheel 51

Mirrors 52

Car Memory, Key Memory 53

Passenger safety systems:

Safety belts 54

Child restraint systems 55

Child-safety locks 56

Airbags 56

Child restraints 59

Installing a child restraint
system 60

Driving:

- Steering/Ignition lock 61
- Starting the engine 61
- Switching off the engine 62
- Parking brake 63
- Manual transmission 64
- Automatic transmission with Steptronic 65
- Turn signal indicator/Headlamp flasher 68
- Wiper/Washer system/Rain sensor 68
- Rear window defroster 70
- Cruise control 71

Everything under control:

- Odometer 73
- Tachometer 73
- Energy Control 73
- Fuel gauge 74
- Temperature gauge 74
- Service Interval Display 74
- Check Control 75
- Clock 75
- Onboard computer 76

Technology for safety and convenience:

- Park Distance Control (PDC) 78
- Dynamic Stability Control (DSC) 79
- Tire Pressure Control (RDC) 80

Lamps:

- Parking lamps/Headlamps 82
- Dash lighting 82
- High beams/Parking lamps 83
- Fog lamps 83
- Interior lamps 83
- Reading lamps 84

Controlling the climate for pleasant driving:

- Automatic climate control 86
- Seat heating 91
- Roller sun blind 91


Interior conveniences:

- HiFi system 92
- Glove compartment 92
- Storage compartments 93
- Cellular phones 95
- Ashtray, front 95
- Cigarette lighter 96
- Ashtray, rear 96


Loading and transporting:

- Through-loading system 97
- Ski bag 98
- Cargo loading 99
- Roof-mounted luggage rack 100

Overview**Controls and features****Operation, care and maintenance****Owner service procedures****Advanced technology****Technical data****Index**



1 The master keys with remote control determine the functions of the Key Memory. Refer to page 53.

 There is an extended-life battery in every master key which is charged automatically in the steering lock as you drive.

For this reason, if you have a master key that is otherwise not used, use that key approximately once every year while driving for an extended period. This will charge the battery. Refer also to page 35. ◀


2 Spare key for storage in a safe place, such as in your wallet. This key is not intended for continuous use.

3 Door and ignition key

The locks for the luggage compartment lid and the glove compartment cannot be operated with this key – this is recommended for valet parking, for instance.

Replacement keys

Replacement keys are available exclusively through your BMW center. Since the keys belong to a security system (refer to "Electronic vehicle immobilizer" on page 33), your BMW center is obligated to be sure that a person requesting a key is authorized to do so.

 If possible, take all of the master keys that belong to the vehicle with you when you pick up your replacement key. When you receive a new replacement key, turn that key to position 2 in the ignition lock once (ignition switched on) and then back. This allows the electronic vehicle immobilizer to "learn" the new key. ◀

Electronic vehicle immobilizer




The key to security

Your BMW is equipped with a passive anti-theft system. This electronic immobilization system is designed to reduce the susceptibility of the vehicle to theft by making it impossible to start the engine using any means other than the special keys furnished with the vehicle. Your BMW center can cancel the electronic system authorization for individual keys (in the event of loss, for instance). A deactivated key can no longer be used to start the engine.

How the electronics work

At the heart of this system is an electronic chip that is integrated into the key. The lock mechanism itself is actually a dual-function device, simultaneously serving as a communications interface designed to allow the security system to maintain a continuous stream of variable, vehicle-specific signals with the electronic circuitry in the key. The system will not release the ignition, fuel injection and starter unless it recognizes an "authorized" key.

 Force applied to the key can damage the integrated electronic circuitry. A damaged key can no longer be used to start the engine. ◀

The concept

The central locking system is ready for operation whenever the driver's door is closed. The system engages and releases the locks on the

- ▷ doors,
- ▷ luggage compartment lid and
- ▷ fuel filler door.

The central locking system can be operated

- ▷ from outside via the door lock and using the remote control
- ▷ from inside by pressing a button.

Activating it from inside does not lock the fuel filler door (see page 38). When the system is actuated from the outside, the antitheft system is activated simultaneously. Both the door locks and the safety lock buttons remain locked. The alarm system* is also armed or disarmed.

If locked from the inside, the central locking system unlocks automatically in the event of an accident. In addition, the hazard warning flashers and interior lamps come on.

**Using the key**

One turn of the key in the driver's door lock unlocks the driver's door only. Turning the key a second time unlocks the passenger-side door, the luggage compartment lid and the fuel filler door.



You can have a confirmation message set to inform you that the car has been properly locked. ◀

You will find additional information on the alarm system* on page 42.

Convenience operating mode

You can also operate the power windows and sliding/tilt sunroof* via the door lock.

- ▷ To open: With the door closed, turn the key to the "Unlock" position and hold it.
- ▷ To close: With the door closed, turn the key to the "Lock" position and hold it.



Watch during the closing process to be sure that no one is injured. Releasing the key stops the operation. ◀

Manual operation

(in the event of electrical malfunction)

Turn the key to the extreme left or right to unlock/lock the door.


Opening and closing – from outside

Using the remote control

The remote control makes opening and locking the doors of your vehicle very convenient. Furthermore, it provides two additional functions that can only be executed by means of the remote control:

- ▷ Switch on the interior lamps
With this function, you can also "search for" your car – when parked in an underground garage, for instance.
- ▷ Open the luggage compartment
The luggage compartment lid will open slightly, regardless of whether the lid was previously locked or unlocked.


The anti-theft system is also deactivated simultaneously when you unlock the vehicle, the alarm system* is disarmed, and the interior lamps are turned on. When you lock the vehicle, the systems are activated and armed, and the lamps go off.


 You can have a confirmation message set to inform you that the car has been properly locked. ◀



Master keys

Keys with remote control are master keys. Refer to page 32.

 Children might be able to lock the doors from the inside. For this reason, always take the vehicle keys with you so that the vehicle can be opened again from the outside at any time. ◀

 Master keys that are used repeatedly are always ready for operation since the battery in the transmitter is charged automatically in the steering lock as you drive.

If it is no longer possible to unlock the vehicle via the remote control, the battery is discharged. Use this key while driving for an extended period in order to charge the battery. Refer also to page 32.

To prevent unauthorized use of the remote control, surrender only the door and ignition key or the spare key (refer to page 32) when leaving the vehicle for valet parking, for example.

In the event of a system malfunction, please contact your BMW center. You can also obtain replacement keys there. ◀

36 Opening and closing – from outside



To unlock the car

Press button 1 to unlock the driver's door only.

Press the button twice in order to unlock the entire vehicle.

Convenience opening mode

Press and hold button 1. The power windows and the sliding/tilt sunroof* are opened.



To lock and secure

Press button 2.



To switch on the interior lamps

After locking the car, press button 2 again.

To switch off the tilt alarm* and interior motion sensor*

Press button 2 again immediately after locking.

For additional information: Refer to page [43](#).


Opening and closing – from outside



To open the luggage compartment

Press button 3.

The luggage compartment lid will open slightly, regardless of whether the lid was previously locked or unlocked.

 Before and after a trip, be sure that the luggage compartment lid was not opened unintentionally. ◀

Panic-Mode (trigger alarm)

By pressing button 3 for two to five seconds, the alarm* can be sounded in the event of danger, if it is armed.

Pressing button 1 will deactivate the alarm.

The LED (light-emitting diode) lights up briefly when the individual buttons are pressed.

Non-BMW systems

The proper functioning of the remote control system may be affected by other units or equipment operating in the immediate vicinity of your car.

If this should occur, you can still open and close the vehicle using the master key in both the door and luggage compartment locks.

For US owners only


The transmitter and receiver units comply with part 15 of the FCC (Federal Communications Commission) regulations. Operation is governed by the following:

FCC ID: LX8EWS
LX8FZVS
LX8FZVE

Compliance statement:


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- ▷ This device may not cause harmful interference, and
- ▷ this device must accept any interference received, including interference that may cause undesired operation.


 Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment. ◀



Use this button to operate the central locking system when the front doors are closed. The doors and luggage compartment lid are unlocked or locked only. The antitheft alarm system is not activated.


 If only the driver's door was unlocked from the outside and you press the button

- ▷ all other doors, the luggage compartment lid and the fuel filler door will be unlocked when the driver's door is opened.
- ▷ the driver's door will be locked again when it is closed. ◀

 If you desire, the central locking system will secure the locks as soon as you start to drive. This can be adjusted to be key-specific. ◀


To unlock and open the doors

- ▷ Either unlock the doors together with the button for the central locking system and then pull each of the release handles above the armrests or
- ▷ pull the release handle for each door twice: The first pull unlocks the door, and the second one opens it.

 Doors locked from outside can be opened from inside by first pressing the button and then pulling a release handle twice. ◀

To engage the locks

- ▷ Use the central locking button to lock all doors at once or
- ▷ press the individual safety lock buttons down. The fuel filler door then remains unlocked. As an added design feature to prevent the driver from being inadvertently locked out of the vehicle, the driver's door safety lock button will not engage as long as the door is open.

 Children might be able to lock the doors from the inside. For this reason, always take the vehicle's keys with you so that the vehicle can be opened again from the outside at any time. ◀



The lock

Only the master key (refer to page 32) fits in the lock of the luggage compartment.



To secure separately

Turn the master key to the right past the resistance point and then pull it out in the horizontal position.

This locks the luggage compartment lid and disconnects it from the central locking system. This feature can be used to prevent unauthorized access to the luggage compartment when you surrender the door and ignition key (refer to page 32) for valet parking, for instance.



To open from outside

Press the button in the handle recess (arrow):
The luggage compartment lid opens slightly.
The luggage compartment is lit when the luggage compartment lid is opened.

Manual operation


(in the event of electrical malfunction)
Turn the master key to the left to the stop – the luggage compartment lid will open slightly.
The luggage compartment is locked again as soon as you close the lid.

40 Luggage compartment lid




Opening from the inside


If the luggage compartment lid has not been locked separately, you can open it with this button in the footwell on the driver's side when the vehicle is stationary.




To close

The handle recesses in the interior trim panel of the luggage compartment lid (arrows) make it easier to pull the lid down.

 To avoid injuries, be sure that the travel path of the luggage compartment lid is clear when it is closed, as with all closing procedures. ◀


 Operate the vehicle only when the luggage compartment lid is completely closed. Otherwise, exhaust fumes could penetrate the interior of the vehicle. Should it be absolutely necessary to operate the vehicle with the luggage compartment lid open:

- ▷ Close all windows. Shut the sliding/tilt sunroof*.
- ▷ Increase the airflow of the automatic climate control to a high level. Refer to page 86. ◀



Floor panel

To raise and secure the floor panel, lift it by the ring and hook it into the rubber seal of the run-off gutter with the hanger (arrow).



Floor mat

You can turn the floor mat over if required (for transporting soiled objects for instance). The rubberized side may be washed. It reduces movement of objects placed on it.

The fittings at the corners of the luggage compartment provide you with a convenient means of attaching luggage nets* and flexible straps for securing suitcases and luggage.

Refer also to "Cargo loading" on page 99.

The concept

The vehicle's alarm system responds:

- ▷ When a door, the hood or the luggage compartment lid is opened
- ▷ To movement inside the vehicle (interior motion sensor)
- ▷ To a change of the vehicle's tilt – if someone attempts to steal the wheels or tow the vehicle without authorization, for example
- ▷ If there is an interruption of battery voltage.

The alarm system signals unauthorized access to the vehicle or an attempted theft in different ways:

- ▷ Sounding an acoustical alarm for 30 seconds
- ▷ The hazard warning flashers are activated for approx. five minutes.

To activate and deactivate the alarm system

When the vehicle is locked or unlocked by using a key or with the remote control, the alarm system is also simultaneously armed or disarmed.

The interior motion sensor is activated approx. 30 seconds after you have finished locking the car.

If the alarm system has been armed correctly, the hazard warning flashers flash once. An acoustic warning signal sounds at the same time.



You can have different acknowledgment messages set to confirm arming and disarming. ◀

You can also open the luggage compartment lid when the system is armed by pressing button 3 of the remote control (refer to page 37). When it is closed, the lid is once again secured.



Indicator lamp displays

The indicator lamp is located under the interior rearview mirror.

- ▷ When the indicator lamp flashes continuously: The system is armed.
- ▷ If the indicator lamp flashes during arming of the system: The door(s), the hood or luggage compartment lid are not completely closed. Even if you do not close the alerted area, the system begins to monitor the remaining areas, and the indicator lamp flashes continuously after 10 seconds. However, the interior motion sensor is not activated.
- ▷ If the indicator lamp goes out when the system is disarmed: No manipulation or attempted intrusions have been detected in the period since the system was armed.

Alarm system*

- ▷ If the indicator lamp flashes for 10 seconds when the system is disarmed: An attempted entry has been detected in the period since the system was armed.

Following triggering of an alarm, the indicator lamp will flash continuously.

Avoiding an unintentional alarm

The tilt alarm sensor and interior motion sensor may be switched off at the same time. You can do this to prevent a false alarm from being triggered (in garages with elevator ramps, for instance), or when the vehicle is transported by trailer or train:

Lock the vehicle twice (= arm the system). Press button 2 on the remote control twice in succession or lock the vehicle twice with the key (refer to page 36).

The indicator lamp lights up briefly and then flashes continuously. The tilt alarm sensor and the interior motion sensor are deactivated as long as the system is armed.



Interior motion sensor

The transmitter and receiver of the interior motion sensor are located in a trim panel in the vehicle's roof.

In order for the interior motion sensor to function properly, the windows and sliding/tilt sunroof must be completely closed.

However, you should switch off the interior motion sensor (see previous column under the heading "Avoiding an unintentional alarm") if you wish to leave the windows or sliding/tilt sunroof open.

- ▷ The tilt sensor and interior motion sensor are deactivated if the convenience closing mode for the windows and the sliding/tilt sunroof is interrupted within the first 10 seconds and then reinitiated. If this happens, you must disarm the system and then re-arm it. ◀

44 Electric power windows



Open and close the windows


In ignition key position 1 or 2:

- ▷ Depress the switch until you feel resistance:
The window will continue to open as long as you hold the switch.
- ▷ Press the switch briefly past the pressure point:
The window will automatically open completely. Pressing the switch again briefly stops the opening cycle.

You can close windows in the same manner by pulling the switch.

Separate switches are located under windows in the rear passenger area.


After the ignition has been switched off: You can still operate the power windows for up to 15 minutes, as long as neither of the front doors has been opened.

 Remove the key from the ignition key and close the doors when you leave the vehicle, so that children cannot operate the power windows and possibly injure themselves. ◀

For the convenience operating mode with the door lock or remote control, refer to page [34](#) or [35](#).

Safety feature


A contact strip is located on the inside upper frame of each of the windows. If pressure is exerted against this contact strip while a window is being raised, the system will respond by stopping the window and then retracting it a small distance.


 Despite this safety feature, be extremely careful to ensure that the closing path of the window is not obstructed. Otherwise, an object might not touch the contact strip in some situations (very thin objects, for instance). You can disable this safety feature by pressing the switch beyond the resistance point and holding it. ◀



Safety switch

You can use the safety switch to deactivate the rear power window switches (when children are in the rear seats, for instance).

 Press the safety switch whenever children are riding in the rear of the vehicle. Careless use of the power windows can lead to injury. ◀

 Exercise care when closing the sliding/tilt sunroof and keep it in your field of vision until it is completely closed. Failure to do so can result in injuries.

Remove the key from the ignition and close the doors when you leave the vehicle so that children cannot operate the sunroof and possibly injure themselves. ◀

To avoid pressure or drafts in the passenger compartment when the sunroof is open or raised, keep the air vents in the dashboard open and increase the air supply if necessary. Refer to page 89.

If the sunroof is completely open, air disturbances may be caused in the vehicle when you are driving at higher speeds. Close the roof as far as is necessary until this natural phenomenon ceases.

For the convenience operating mode with the door lock or the remote control, refer to page 34 or 35.



Lifting - Opening - Closing

In ignition key position 1 or 2, press the switch or slide it to the desired direction until you feel resistance.

When lifting, the headliner retracts several inches.

After the ignition has been switched off, you can still operate the sunroof for up to 15 minutes, as long as neither of the front doors has been opened.

Automatic opening and closing

▷ Press the switch past the resistance point briefly: The sunroof travels to either the fully-closed or fully-open position.

46 Sliding/Tilt sunroof*

- ▷ With the sunroof open, press the switch briefly toward "Lift." The sunroof automatically extends to its fully raised position.

Pressing the switch again briefly stops the motion immediately.

Safety feature

If the sliding/tilt sunroof encounters resistance at a point roughly past the middle of its travel when it is closing, the closing cycle is interrupted and the sunroof will open again slightly.



Despite this safety feature, always be careful to ensure that the closing path of the roof is not obstructed. Otherwise, an object might not touch the contact strip in some situations (very thin objects, for instance). You can disable this safety feature by pressing the switch beyond the resistance point and holding it. ◀

Power loss or malfunction

In the event of an electrical system malfunction, the sliding/tilt sunroof can be manually operated. Refer to page [156](#).

Seat adjustment

For your personal safety when adjusting the seat position, please follow the instructions below carefully:

⚠ Never try to adjust your seat while operating the vehicle. The seat could respond with an unexpected movement, and the ensuing loss of vehicle control could lead to an accident. Be sure that the safety belt remains firmly against your body at all times. In the event of a frontal impact, a loose lap belt could slide over the hips, leading to abdominal injury. In addition, the safety belt's restraint effectiveness is reduced if the belt is worn loosely. Never ride with the backrest reclined to an extreme angle (especially important for the front passenger to remember). If you do so, there is a risk that you will slide under the safety belt in an accident, thus reducing the protection provided by the safety belt. ◀

Mechanical seat



- 1 **Longitudinal adjustment**
Pull the lever and slide the seat to the desired position.
After releasing the lever, apply pressure to the cushion to ensure that the latch engages securely.
- 2 **Cushion height**
Pull the lever and apply weight to or remove weight from the seat as required.



- 3 **Backrest angle**
Pull the lever and apply weight to or remove weight from the backrest as required.


Correct sitting posture

To reduce strain on the spinal column, sit all the way back in the seat and rest your back fully against the backrest.

In the ideal sitting posture, your head is positioned along a straight line in relationship to your spinal column.

For long-distance driving, you may wish to increase the backrest angle slightly to reduce muscular tension. You should be able to grasp the steering wheel at its highest point with your arms slightly bent.

After a seat adjustment, adjust the height of the safety belt also. Refer to page 54.

Head restraints**Adjustments**

Height: Adjust by pulling up or pushing down.



In order to move to the lowest positions, press button 1. ◀

To adjust the angle of the front head restraints:

Rotate them in the desired direction.



Head restraints reduce the risk of injury to the cervical vertebra in the event of an accident.

Adjust the head restraint so that its center is approximately at the height of your ears. ◀

**Removal**

- ▷ Pull the head restraint upward to the stop.
- ▷ Press the button (arrow) and remove the head restraint.

Installation

- ▷ Press the button (arrow) and insert the head restraint into the guides.
- ▷ Adjust the head restraint.



With this seat, you can also adjust the tilt angle and the thigh support:


- 1 To adjust the tilt angle upward:
Pull the lever as often as necessary to reach the desired angle.
- 2 To adjust the tilt angle downward:
Push the lever as often as necessary to reach the desired angle.
- 3 Thigh support area:
Pull the lever and adjust the position of the cushion for thigh support as desired.



You can adjust the backrest's contour for additional support in the curvature of your spine's lumbar region.


The upper hips and spinal column receive supplementary support to help you maintain a relaxed, upright posture.

- ▷ Press the front/rear of switch: Increase/Decrease curvature.
- ▷ Press the upper/lower end of the switch: Increase the upper/lower curvature.



- 1 Backward/Forward adjustment
- 2 Cushion height
- 3 Backrest angle

The head restraint is adjusted manually.


 Please refer to the adjustment instructions on page 47 to reduce the risk of personal injury. ◀




BMW Sports Seat


- 1 Tilt angle
- 2 Backward/Forward adjustment
- 3 Cushion height
- 4 Backrest angle

The head restraint and the thigh support area are adjusted manually.

 Please refer to the adjustment instructions on page 47 to reduce the risk of personal injury. ◀



You can store and recall three different driver's seat and outside mirror positions.

 The adjustment setting of the lumbar support is not saved in the memory. ◀

To store

- 1 Turn the key to ignition key position 1 or 2.
- 2 Adjust your seat and outside mirrors to the desired position.
- 3 Press the **MEMORY** button: The indicator lamp in the button lights up.
- 4 Press memory button 1, 2 or 3 as desired: The indicator lamp goes out.

To select a stored setting

Convenience function:


- 1 Open the driver's door after unlocking or set the ignition key in position 1.
- 2 Briefly press memory button 1, 2 or 3 as desired.

The adjustment cycle is canceled immediately if you press a seat adjustment switch or one of the memory buttons.

Security function:

- 1 With the driver's door closed and the ignition key either removed or in position 0 or 2
- 2 Maintain pressure on the desired memory button (1, 2 or 3) until the adjustment process is completed.

If you press the **MEMORY** button accidentally: Press the button a second time; the indicator lamp goes out. ◀

 Do not select a memory position while the vehicle is moving. If you do so, there is a risk of accident from unexpected seat movement. ◀

Seat and mirror memory*



Your BMW center can adjust your vehicle's systems in such a manner that your personalized settings are automatically set for the seat and outside mirror positions when you unlock the vehicle with your personal remote control. ◀



If you make use of this method of adjustment, be sure that the footwell behind the driver's seat is unobstructed before unlocking the vehicle. If you fail to do so, persons or objects could be injured or damaged if the seat should move backward. ◀



Passenger side exterior mirror tilt function

(automatic curb monitor)

- 1 Move the mirror selector switch 1 to the "driver's mirror" position.
- 2 When the selector lever is placed in "Reverse," the passenger-side mirror tilts downward. This allows the driver to see the area directly adjacent to the vehicle during parking (curbs, etc.).

You can deactivate this automatic feature: Set the mirror selection switch to the "passenger side" position.


Adjusting steering wheel 51



- 1 Push the locking lever downward.
- 2 Adjust the steering wheel (fore/aft and up/down) to the desired position.
- 3 Pull the lever back in to clamp the steering wheel in the new position.



Do not adjust the steering wheel while the vehicle is moving. If you do so, there is a risk of accident from unexpected movement. ◀



Exterior mirrors

- 1 Switch for 4-way adjustment
- 2 Selection switch for changing between mirrors

You can also adjust the mirrors manually by pressing against the outer edges of their lenses.



The mirror on the passenger's side features a lens with a more convex surface than the mirror installed on the driver's side. When estimating the distance between yourself and other traffic, bear in mind that the objects reflected in the mirror are closer than they appear. Estimations of the distance to following traffic should therefore not be regarded as precise. This is also true for the aspherical section of both exterior mirrors. ◀

Electric defrosting

Both mirrors are automatically defrosted with the ignition key in position 2.



Interior rearview mirror

To reduce glare from behind when driving at night, tilt the small lever forward.

Lighted vanity mirror*

Fold down the sun visor and slide the cover panel to the side as required.

The mirror lamps operate in ignition key positions 1 and 2.

Sun visors

These can be folded down toward the windshield or swiveled out against the side windows.



Interior rearview mirror with automatic dimming feature*

By responding to the effects of ambient light and the glare from following traffic, this mirror automatically dims through an infinitely-variable range.

The mirror switches to its clear, undimmed mode whenever the transmission is placed in reverse gear (selector lever in "Reverse").

To ensure that the mirror continues to operate properly, keep the two photocells clean and unobstructed. One photocell (arrow) is in the mirror glass, while the other is offset somewhat on the other side of the mirror.

For an explanation of the electrochromic technology used in this mirror, refer to page [165](#).



How the system functions

You have probably frequently wished that you could configure individual functions of your vehicle to reflect your own personal requirements. In engineering your vehicle, BMW has included several user-defined functions in the vehicle's design. Your BMW center can make these settings for you in accordance with your wishes.

There are settings related to the vehicle ("Car Memory") and settings related to individuals ("Key Memory"). You can have up to four different basic settings adjusted for four different persons. The only requirement is that each person uses his or her own remote control key. When your vehicle is unlocked with the remote control, the vehicle recognizes

the individual user by means of a data exchange with the key, and makes adjustments accordingly.

In order for you to distinguish between different keys, colored decals are supplied together with the keys.


What the system can do

Your BMW center can provide you with details on the capabilities of the Car Memory and Key Memory systems.



You will see this symbol throughout the Owner's Manual. It is to remind you at appropriate places of the settings that are available to you. ◀

An example of Key Memory is the automatic adjustment of the driver's power seat* with settings stored in the memory for the individual driver when the vehicle is unlocked.




Fasten your safety belt at the beginning of every trip.

To fasten:

Make sure you hear the catch engage in the belt buckle.

To release:

Press the red button in the buckle. Hold the belt and guide it back into its reel.



Safety belt height adjustment

You can adjust the safety belts to fit your own physical dimensions by using the safety belt height adjustment.

Slide the button downward or upward.

In the rear, the belt buckle with the word "CENTER" is provided exclusively for the passenger sitting in the middle.



For your safety, please comply with the following instruction for wearing safety belts. If you do not, the safety belts may not be able to provide their maximum protection. The following information also applies to your passengers:

Never allow more than one person to wear a single safety belt. Never allow infants or small children to ride in a passenger's lap.

Avoid twisting the belt while routing it firmly across your hips and shoulder. Do not allow the belt to rest against hard or fragile objects in your pockets. Never route the belt across your neck, do not run it across sharp edges and be sure that the belt does not become caught or jammed.


Be sure that the safety belt fits snugly against your body at all times, and avoid wearing clothing that prevents the belt from fitting properly. Pull on the belt periodically to readjust the tension across your shoulder. In the event of a frontal impact, a loose lap belt could slide over your hips, leading to abdomi-

Safety belts

nal injury. In addition, the safety belt's restraint effectiveness is reduced if the belt is worn loosely.

Expectant mothers should also wear the safety belt, taking special care to place the lap belt over the lower hips, where it does not exert pressure on the abdominal area. ◀

For care instructions, refer to "Car care" page [135](#).

 If the safety belt system has been subjected to the stresses involved in an accident or otherwise damaged: Have the entire safety belt mechanism replaced by your BMW center, including the safety belt tensioner. In addition, have your BMW center inspect the safety belt anchors. If a child restraint system was in the vehicle during an accident, consult the manufacturer's instructions regarding replacement. ◀

Child restraint systems*




Never install a rear-facing child restraint device on the front passenger seat. Injuries could occur if the airbag is triggered in the event of an accident.

Children should always ride in the rear. Do not modify the child restraint system in any way. If you do so, it will not provide your child with maximum protection. ◀



On a rear door, the push the safety lever downward:


The door can now be opened from the outside only.



- 1 Front airbags for driver and passenger
- 2 Side impact Head Protection System (front)
- 3 Side airbags (front and rear*).

Protective effect

The front airbags supplement the three-point safety belts by providing additional protection for the front-seat occupants in the event of a severe frontal collision on which the protection afforded by the belts alone may no longer be sufficient. The head and side airbags help provide protection in the event of a side impact. Each of the side airbags is designed to help support the upper body.



The illustration depicts schematically the primary directions of vehicle impact that initiate an airbag deployment.

Airbags

Indicator lamp



The indicator lamp displays the operational status of the airbag system when the ignition key is in position 1 and higher.

System operational:

- ▷ The indicator lamp comes on briefly then goes out.

System malfunction:

- ▷ The indicator lamp fails to come on.
- ▷ The indicator lamp comes on briefly before going out, and then lights up again.

If there is a system malfunction, there is a risk that the airbags will not be triggered within their normal response range, even if the level of impact would normally have triggered them.

Have your BMW center inspect and repair the system immediately.



The airbag indicator lamp also comes on if the safety belt tensioners have been triggered. ◀



For your own safety, please comply with the following precautions concerning airbags. If you do not, their protective function may be impaired and your personal safety endangered. The following information pertains to all occupants:

The airbags are supplemental restraint devices designed to provide extra protection; they are not a substitute for safety belts. Wear your safety belt at all times. The airbags will not be triggered in the event of a minor accident, a vehicle roll-over, or collisions from the rear. In these instances, the safety belt offers the best protection.

Airbags are located under the cover panels in the steering wheel, in the instrument panel, in the side trim panels in the front and rear*, in the roof panels, and in the sides of the inside roof lining. Select a seat position that is comfortable and allows the greatest possible distance from each of the applicable airbags. Hold the steering wheel at the rim (hands at the "9 o'clock and 3 o'clock" positions) in order to avoid injuries to your hands or arms if the airbag is triggered.

Never allow any objects to obstruct the area between the airbag and an occupant.

Do not use the cover panel above the front passenger airbag as a storage area.

Never tape the airbag cover panels, cover them over or alter them in any other way.

Never install a rear-facing child restraint device on the front passenger seat. Children under 13 years of age and children who are smaller than 5 feet (150 cm), should only travel in the rear seat.

If your vehicle is equipped with side airbags in the rear, be sure that child seats are installed correctly and with the greatest possible distance from the side trim panels. Do not allow children to lean out of the child's seat in the direction of the side trim panels. Otherwise, serious injuries could occur if the airbag is triggered.

At all times, occupants should sit upright and be properly restrained (infants and small children in appropriate child restraint systems; larger children and adults using the safety belts). Never let an occupant's head rest near or on a side airbag because the inflating airbag could cause a serious or fatal injury. Please note that the word "Airbag" imprinted on the door trim panel indicates the airbag's location.

58 Airbags

Accident research shows that the safest place for children in an automobile is in the rear seat. However, a child sitting in the rear seat and not properly restrained may place his or her head on or near the side airbag, if so equipped. For example, a child – even though belted – may fall asleep with his or her head against the side airbag. It may be difficult for a driver to ensure that children in the rear seat will remain properly positioned at all times and not place their heads on or near the side airbag. Therefore, we recommend that the rear seat side airbags, if provided, be deactivated if you plan to transport children in the rear seat. The rear seat side airbags may already have been deactivated, either at the time of manufacture or by a BMW center. Labels in the rear door opening should indicate the status of your rear seat side airbags. If you are uncertain of their status, or wish to have the airbags activated or deactivated, please contact your BMW center. ◀

Even when all these guidelines are observed, there is still a small residual risk of injuries to the face, hands and arms occurring from airbag deployment in isolated instances. The ignition and inflation noise may induce a mild temporary hearing loss in sensitive individuals.


For additional information concerning the airbag system: Refer to pages [137](#) and [163](#).



This is the right way for a child to sit in a child restraint when rear side airbags (arrow) are provided.



This is the right way for a larger child to sit wearing the safety belt when rear side airbags (arrow) are provided.




Commercially available child seats complying with the legal standard are designed to be secured with a lap belt or with the lap belt portion of a combination lap/shoulder belt. Improperly or inadequately installed restraint systems can increase the risk of injury to children. Always read and follow the instructions that come with the system.

If you use a child restraint system with a tether strap, three additional tether anchorage points (refer to the arrows in the illustration) have been provided. Depending on the location selected for seating in the rear passenger area, attach the tether strap to the corresponding anchorage point to secure the child restraint system. Remove the cover first on the middle location.

If the respective seating position is fitted with a headrest lift the headrest and pass the tether strap between the headrest and the seat back.

Adjust the tether strap according to the child restraint manufacturer's instructions.

 Before installing any child restraint device or child seat, please read the following:

Never install a rearward-facing child restraint system in the front passenger seat of this car.

Your car is equipped with an airbag supplemental restraint system for the front passenger. Because the backrest on any rear-facing child restraint system (of the kind designed for infants under 1 year and 20 lbs.) would be within the airbag's deployment range, you should never mount such a device in the front passenger seat, since the impact of the

airbag against the child restraint's backrest could lead to serious or fatal injuries.

If it is necessary for a child (not an infant) to ride in the front seat, certain precautions should be taken. First, move the passenger seat as far away from the dashboard as possible. This important precaution is intended to maximize the distance between the airbag and the child. Older children should be tightly secured with the safety belt. Younger children should be secured in an appropriate forward-facing child restraint system that has first been properly secured with a safety belt.

Never install a rear-facing child restraint system in the front passenger seat.

We strongly urge you to carefully read and comply with the instructions for installation and use provided by the child restraint's manufacturer whenever you use such a device.

Be sure that all occupants (of all ages) remain properly and securely restrained at all times. ◀

All rear seating positions in your vehicle meet the recommendations of SAE J1819, an industry recommended practice for securing child restraint systems in motor vehicles.

Installing a child restraint system



All of the rear belt retractors and the front passenger's safety belt can be locked for mounting and securing child restraint systems.

Information pertaining to this is located in the immediate vicinity of the buckle latch of each safety belt.

Lock the safety belt

Extract the entire length of the belt from the inertia reel mechanism. Allow the reel to retract the belt somewhat and engage the buckle, then tighten the belt against the child restraint system. The retraction mechanism is now locked. The belt cannot be extracted further. Always comply with the installation instructions provided by the manufacturer of the child restraint system.

Unlock the safety belt

Release the safety belt, remove the child's seat and pull the safety belt out to its end position on the belt retractor.




0 Steering lock engaged

The key can only be inserted or removed in this position.

After removing the key, turn the steering wheel slightly to the left or right until the lock engages.

If the key is not removed, an acoustic signal is sounded after the driver's door has been opened.

 Vehicles with automatic transmission:

Do not move the selector lever from the "Park" position until the engine is running (ignition key at position 2). In order to turn the key back to position 0 or to remove it, move the selector lever into position "Park" first (Interlock). ◀


1 Steering lock disengaged

Turning the steering wheel slightly to the right or left often makes it easier to turn the key from 0 to 1. Individual electrical devices are ready for operation.

2 Ignition on


All electrical equipment and accessories are available for use.

3 Starting the engine

 Vehicles with manual transmission: Depress the clutch when starting the vehicle. A lockout prevents the engine from starting if the clutch is not depressed. ◀


Before starting

- ▷ Engage the parking brake.
- ▷ Be sure that the shift lever is in "Neutral" (or "Park" if the vehicle is equipped with an automatic transmission).
- ▷ Manual transmission: Depress the clutch pedal.
- ▷ Automatic transmission: Depress the footbrake.

 Do not run the engine in enclosed areas. The exhaust gases contain carbon monoxide, an odorless and colorless, but highly toxic gas. Breathing the exhaust gases poses an extreme health risk, and can lead to unconsciousness and death.

Do not leave the car unattended with the engine running. An unattended vehicle with a running engine represents a potential safety hazard. ◀

- ▷ Start the engine. Do not press the accelerator pedal.

 Do not actuate the starter for too short a time, but not turn it for more than approx. 20 seconds. Release the ignition key immediately when the engine starts.

Do not allow the engine to warm up by leaving it running while the vehicle remains stationary. Instead, begin driving immediately at a moderate engine speed. ◀

62 Starting the engine

If the engine does not start on the first attempt (if it is very hot or cold, for instance):

- ▷ Press the accelerator pedal halfway down while engaging the starter.

Cold start at extremely low temperatures, from approx. + 5 °F (- 15 °C) and at elevations above 3,300 feet (1,000 meters):

- ▷ On the first start attempt, engage the starter for a longer period (approx. 10 seconds)
- ▷ Press the accelerator pedal halfway down while engaging the starter.

Switching off the engine

Turn the ignition key to position 1 or 0.



Do not remove the ignition key while the vehicle is still moving. If you did so, the steering lock would engage when the steering wheel is turned.

When you leave the vehicle, always remove the ignition key and engage the steering lock.

Vehicles with manual transmission:

Always engage the parking brake when parking on slopes and inclined surfaces. Placing the lever in 1st gear or reverse may not provide adequate resistance to rolling.

Vehicles with automatic transmission:

Place the selector lever in "Park." ◀

Parking brake



To engage

The lock engages automatically when you lift the lever. The indicator lamp in the instrument cluster lights up in ignition key position 2. Refer to page 21.

To release

Pull up slightly on the lever, press the button and lower the lever.

The parking brake is designed primarily to prevent the vehicle from rolling when it is parked. It operates against the rear wheels.



If, in exceptional circumstances, it should be necessary to engage the parking brake while the vehicle is in motion, do not pull the lever with excessive pressure. Keep your thumb pressed against the release button while carefully pulling the lever up to apply moderate pressure. Excessive pressure can lead to over-braking and loss of traction (fishtailing) at the rear axle.

The brake lamps do not come on when the parking brake is engaged.

Vehicles with manual transmission:

Always engage the parking brake when parking on slopes and inclined surfaces. Placing the lever in 1st gear or reverse may not provide adequate resistance to rolling.

Vehicles with automatic transmission:

Place the selector lever in "Park." ◀

To avoid corrosion, apply the parking brake lightly from time to time when coasting to a standstill (at a traffic signal, for instance), provided that it is safe to do so.

64 Manual transmission



The shift lever's neutral plane (dot in the illustration) is located between 3rd and 4th gears.

When shifting from each gear into "Neutral," the shift lever returns automatically to this neutral position because of its spring loading.

Reverse

Select "Reverse" only when the vehicle is at a complete stop. Press the shift lever to the left to overcome the slight resistance.

As you do this, the backup lamps will turn on automatically when the ignition key is in position 2.



Do not hold the vehicle in place on slopes by slipping or "riding" the clutch. Use the parking brake instead. A slipping clutch increases clutch wear. ◀

You have the option of driving with a normal automatic transmission or switching to manual.

When you move the selector lever from the "D" position to the left into the M/S range, the performance-oriented shift programs of the automatic transmission are engaged. As soon as you briefly touch the selector lever in the "+" or "-" direction, Steptronic changes the gear. The manual mode is engaged. Whenever you want to use automatic again, just shift the selector lever toward the right to position D.

The automatic transmission with Steptronic is equipped with ATC (Adaptive Transmission Control). ATC reacts with precision to your individual driving style and the current driving conditions. It is for this reason that various shift programs are used.

For additional details concerning the ATC, please refer to the chapter describing "Advanced technology" on page 162.



Selector lever positions


P R N D M/S + -


Starting the engine

The engine can only be started in selector lever positions P ("Park") or N ("Neutral").

Range selection

A detent prevents inadvertent shifts into certain selector lever positions. To disengage the detent, press the button on the front of the shift knob (arrow).

 While the vehicle is stationary and before shifting out of "Park" or "Neutral," depress the footbrake in order to disengage the selector lever's lock mechanism (Shiftlock). Hold the footbrake down until starting off. Otherwise the vehicle will "creep" when a drive position is engaged. ◀

 If you leave the vehicle with the engine running, move the selector lever to the "Park" or "Neutral" position and apply the parking brake. If you fail to do this, the vehicle could move. Do not leave the car unattended with the engine running. An unattended vehicle with a running engine represents a potential safety hazard. ◀

P Park

Select only when the vehicle is stationary. The transmission locks to prevent the rear wheels from turning.

R Reverse

Select only when the vehicle is stationary.

N Neutral

Select only if your journey is interrupted for a long period.

D Drive (automatic shift program)

This position is designed for driving under all normal operating conditions. All forward gears are available.

"Kickdown"

In the "Kickdown" mode, you achieve the maximum acceleration and the top speed in position D.

To activate this mode, depress the accelerator pedal beyond the full-throttle position, at which a resistance point must be overcome.




M/S Manual operation and Sport Program

Shifting from D into M/S activates the Sport Program. This is indicated by "SD" in the gear selection display. This position is recommended for a performance-oriented driving style.

With the first brief touch, the automatic transmission shifts from the Sport Program to the manual mode.

When you move the selector lever forward in the "+" direction, the transmission shifts up. When the lever is moved back in the "-" direction, the transmission shifts down. M1 to M5 appear in the gear indicator.

Upshifts or downshifts will only be carried out by the ATC at appropriate engine speeds and road speeds. If the engine speed is too high, for instance, a downshift will not be executed. The gear selected will appear briefly in the instrument cluster followed by the current gear.

 To accelerate quickly in the manual mode (to pass another vehicle, for instance), shift down manually or employ the kickdown mode. ◀

Shifting from M/S to the selector lever positions P, R and N is possible only by going through D.

In the following situations, the Steptronic "thinks" for you in the manual mode:

- ▷ In order to prevent the engine from overrevving, the transmission shifts automatically to the next higher gear just before the RPM cutoff point.
- ▷ If you do not do anything to intervene, it will automatically downshift at lower speeds.
- ▷ In kickdown, it will downshift into the lowest gear possible, depending on the engine speed.
- ▷ According to the situation, for instance in wintry conditions, the vehicle can be started in 2nd or 3rd gear.



Available displays

P R N D SD M1 M2 M3 M4 M5

Electronic transmission control module



If the indicator lamp comes on, there is a malfunction in the transmission system.

Bring the vehicle to a stop, select transmission position "P," set the parking brake and turn the engine off (ignition key to position 0).

Wait a few seconds, then start the engine.

If the indicator lamp goes out after a few seconds, normal transmission performance has been restored. You may continue to drive as usual.

If the indicator lamp does not go out, you can place the selector lever in all positions. However, the vehicle will now only operate in 3rd and 4th gear.


If this happens, avoid extreme engine loads and consult the nearest BMW center.



Do not work in the engine compartment when a drive gear (forward or reverse) is engaged. If you do this, the vehicle could move. ◀

For towing, tow-starting or jump-starting the vehicle, refer to the information beginning on page [157](#).

68 Turn signal indicator/Headlamp flasher



To signal briefly

Press the lever up to but not beyond the detent. It then returns to the center position when released.

- 1 High beams (blue indicator)
- 2 Headlamp flasher (blue indicator)
- 3 Turn signal indicator (green indicator lamp accompanied by periodic clicking sound from the relay).

If the indicator lamp and the clicking from the relay are both faster than normal, one of the turn indicators has failed.

Wiper/Washer system



- 0 Wipers retracted
- 1 Intermittent wipe or rain sensor*
- 2 Normal wipe
- 3 Fast wipe
- 4 Brief wipe
- 5 Automatic windshield washer
- 6 Rotary dial for control of the wipe interval or the sensitivity of the rain sensor.

Wiper/Washer system

1 Intermittent wipe or rain sensor*

Intermittent wipe:

You can use rotary dial 6 to select from four wipe intervals.

In addition, the wipe interval automatically adapts to variations in road speed.

Rain sensor:

The rain sensor is positioned on the windshield, directly ahead of the interior rearview mirror. When the rain sensor is activated, the windshield wiper is controlled automatically, depending on the degree of wetness of the windshield (in both snow and rain). You do not have to be concerned with switching the windshield wiper on or off or adjusting the wipe interval between intermittent and full wipe. Instead, you can concentrate fully on the traffic conditions. This is especially important under adverse weather conditions.

To activate the rain sensor:

In ignition key positions 1 or 2, move the lever to position 1. The wipers travel once across the windshield, regardless of the weather.

You can leave the lever permanently in position 1, and then activate the rain sensor in ignition key positions 1 or 2.

To do this,

- ▷ turn rotary dial 6 briefly or
- ▷ use the automatic windshield washer 5.

To modify the sensitivity of the rain sensor:

Turn rotary dial 6.



Turn the rain sensor off when passing through an automatic car wash. Failure to do so could result in damage caused by undesired wiper activation. ◀

2 Normal wiper speed

When the vehicle is stationary, the wipers switch automatically to intermittent wipe (not on vehicles with rain sensor).

3 Fast wiper speed

When the vehicle is stationary, the wipers operate at normal speed (not on vehicles with rain sensor).

5 Automatic windshield washer

The system sprays washer fluid against the windshield and activates the wipers for a brief period.

If you pull the lever only briefly, the system sprays washer fluid onto the windshield without activating the wipers.

Headlamp washers*

When the vehicle's lighting system is switched on, the headlamps will also be cleaned every fifth time the automatic windshield washer is activated.



Do not use the washers if there is any danger that the fluid will freeze on the windshield. If you do so, your vision could be obscured. Use an antifreeze agent. Refer to page 124.

Do not use the washers when the reservoir is empty. If you do so, the washer pump could be damaged. ◀

Windshield washer jets

The windshield washer jets are heated* automatically when the ignition key is in position 2.

**To deactivate**

Press the button if the indicator lamp is on.

To activate

Press the button: As long as the indicator lamp remains on, the rear window defroster continues at high-output (rapid thaw).

After the indicator lamp goes out, the defroster continues operating at reduced power for a limited period before deactivating automatically.



You can store and automatically maintain any desired vehicle speed above approx. 20 mph (30 km/h).


To activate the system

In ignition key positions 1 or 2:
Press button 1. The indicator lamp in the instrument cluster comes on. You can now use the cruise control.

To store and maintain speed or to accelerate

Press button 3 briefly:
The system registers and maintains the current vehicle speed. The speed will now be increased by approx. 0.6 mph (approx. 1 km/h) every time you briefly press the button.

Press and hold button 3:
The vehicle accelerates without pressure on the accelerator pedal. When you release the button, the system registers and maintains the current speed.

 If, on a downhill gradient, the engine braking effect is not sufficient, the controlled speed may be exceeded. Speed may drop on uphill grades if the engine output is insufficient. ◀

To decelerate

Press button 2 briefly:
When the cruise control is active, vehicle speed is reduced by approx. 0.6 mph (approx. 1 km/h) every time you briefly press the button.

Press and hold button 2:
With the cruise control active, the system automatically reduces the throttle opening to slow the vehicle. When you release the button, the system registers and maintains the current speed.

To cancel the cruise control

When the system is activated, press and hold button 1. The indicator lamp stays on. You can use the cruise control again as desired.

In addition, cruise control is canceled automatically:

- ▷ if the brakes are applied
- ▷ if the clutch is depressed or the automatic transmission selector lever is moved from "Drive" to "Neutral"
- ▷ if you exceed or fall below the programmed speed for an extended period (by depressing the accelerator, for example).

To resume the stored setting

Press button 4:

The vehicle accelerates to and maintains the last speed stored. When you turn the ignition key to position 0, the stored speed is deleted from the system's memory and the system is deactivated.

To deactivate the system

When the cruise control has been canceled, press button 1 again. The indicator lamp goes off and the stored speed is canceled.



Do not use cruise control on twisting roads, when high traffic density prevents driving at a constant speed, when the road surface is slick (snow, rain, ice), or when the road surface is loose (rocks, sand). ◀



1 Odometer

You can activate the displays shown in the illustration with the ignition key in position 0 by pressing the button in the instrument cluster (arrow).

2 Trip odometer

To reset the trip odometer to zero, press the button (arrow) with the ignition key in position 1 or 2.



Avoid engine speeds in the red warning zone of the gauge.

To protect the engine, the fuel supply is automatically interrupted in this zone; you will notice a loss of power.



Indicates the current fuel consumption in mpg (in l/100 km for Canadian models). You can check your current driving style to see whether it is conducive to economy and minimum exhaust emissions.

The needle goes back to zero when the car is not moving.

74 Fuel gauge



When you switch on the ignition, the indicator lamp comes on briefly to confirm that the system is stationary.

Once the indicator lamp begins to light up continuously, there are still approx. 2.1 gallons (8 liters) of fuel in the fuel tank.

Tank capacity: page [175](#).

If the tilt of the vehicle varies (extended driving in mountainous areas, for example), there may be slight fluctuations of the needle.



Fill the fuel tank well before it is empty. Driving to the last drop of fuel can result in damage to the engine and/or the catalytic converter. ◀

Temperature gauge



Blue

The engine is still cold. Drive at moderate engine and vehicle speeds.

Red

When you switch on the ignition, the indicator lamp comes on briefly to confirm that the system is operational.

If the lamp comes on while operating the vehicle: The engine is overheated. Stop and switch the engine off immediately and allow it to cool down.

Between the blue and red zones

Normal operating range. It is not unusual for the needle to rise as far as the edge of the red zone in response to high outside temperatures or severe operating conditions.

Checking coolant level: page [128](#).

Service Interval Display



Remaining distance for service


The displays shown in the illustration appear for a few seconds when the ignition key is in positions 1 and 2 or after the engine is started.

The next service due appears with the message OILSERVICE or INSPECTION, together with the remaining distance before scheduled service.

The computer bases its calculations of the remaining distance on the rate of fuel consumption in the period immediately preceding your data request.

A flashing message and a "-" in front of the number mean that the service interval has already been exceeded by the distance shown on the display. Please contact your BMW center for an appointment.

Check Control



Graphic display

The following information and/or conditions are indicated using symbols, starting with the ignition key position 2, until the condition has been corrected.

- 1 Inspect the low-beam and high-beam headlamps, as well as the side lamps
- 2 Door open
- 3 Luggage compartment lid open
- 4 Check brake and tail lamps.

After the completion of a trip and when the driver's door is opened, an acoustical signal is given for "Lamps on" if the lamps have not been switched off.

Clock

If you wish to have a permanent time display, you can make this adjustment in the radio display (refer to the Radio Owner's Manual).

You can adjust the clock and the time display in the car radio as follows.



Adjustments

In ignition key position 1 and 2


To set ahead: Turn the button to the right.

To set back: Turn the button to the left. The adjustment speed will increase the longer you continue to hold the button.

To change the display mode: Press the knob briefly.

Every time you press the knob, the clock display alternates between the 12-hour or 24-hour mode.

In ignition key position 0: The time is displayed for a few seconds after you press the left button (refer to "Odometer" on page 73).



Mode selection

In ignition key positions 1 and 2, you can call up information from the onboard computer using the button in the turn signal lever. By pressing the button briefly in the direction of the steering column, you can call up a new function for display.

The displays appear in the following order:

Time, outside temperature, average fuel consumption, cruising range, average vehicle speed.

The function that was last selected will be displayed when the ignition is switched on.



Outside temperature

You can change the units of measurement for the outside temperature display (°C/°F) by pressing the right-hand reset button in the instrument cluster when the temperature display is active.

Ice warning

If the outside temperature drops to approx. +37.5 °F (+3 °C), the onboard computer switches automatically to the outside temperature display. In addition, a signal sounds as a warning and the display flashes for a brief period.

The warning is repeated whenever the temperature climbs to at least +43 °F (+6 °C) following the last warning and then drops back to +37.5 °F (+3 °C).



The ice warning does not alter the fact that surface ice can form at temperatures above +37.5 °F (+3 °C), on bridges or shaded road surfaces, for instance. ◀



Average fuel consumption

If you continue to hold the button on the turn signal lever, the average fuel consumption last displayed is recalculated from that point.



Range

The computer bases its calculations of the cruising range on the rate of fuel consumption in the period immediately preceding your data request.



Average speed

If you continue to hold the button on the turn signal lever, the average fuel consumption last displayed for that speed is recalculated from that point in time.

Any time spent when the vehicle is stationary and the engine is shut off is ignored for the calculation.

The PDC assists you when you back into a parking space. A signal warns you of the distance to an obstacle. To do this, four ultrasonic sensors in the rear bumper measure the distance to the nearest object. The monitoring range of the two corner sensors extends to approx. 2 feet (60 cm) behind the bumper. The two center sensors cover a distance of approx. 4.9 feet (1.50 meters).

The system starts to operate automatically about one second after you select reverse with the ignition key in position 2. PDC is deactivated when you shift back out of reverse.

Acoustical signals

The distance to the nearest object is indicated by a tone sounding at various intervals. As the distance between vehicle and object decreases, the intervals between the tones become shorter. A continuous warning tone sounds if the distance to a recognized object is less than 1 foot (30 cm).

The warning signal is canceled after approx. three seconds if the distance to the obstacle remains constant during this time (if you are moving parallel to a wall, for instance).

System malfunctions will be indicated by a continuous high-pitched tone when the system is activated the first time. Please refer the problem to your BMW center.



The PDC does not remove the driver's personal responsibility for evaluating the distance between the vehicle and any obstacles. Even when sensors are involved, there is a blind spot in which objects cannot be detected. This applies especially in those cases where the system approaches the physical limits of ultrasonic measurement, as occurs with tow bars and trailer couplings, and in the vicinity of thin and painted objects. Certain sources of sound, such as a loud radio, could drown the PDC signal tone. ◀



Keep the sensors clean and free of ice or snow in order to ensure that they continue to operate effectively. Do not apply high-pressure spray to the sensors for a prolonged period of time. Maintain an adequate distance of more than approx. 4 inches (10 cm). ◀



The concept

DSC maintains vehicle stability, even in critical driving situations.

The system optimizes vehicle stability during acceleration and when starting from a full stop, as well as optimizing traction. In addition, the system recognizes unstable vehicle conditions (understeering or oversteering, for example) and holds the vehicle on a sure course by intervening via the engine and by braking intervention at the individual wheels.

The system activates automatically each time you start the engine.

Indicator lamp



The indicator lamp in the instrument cluster goes out shortly after you switch on the ignition.

Refer to pages [21](#) and [22](#).

Indicator lamp flashes:

The system is actively regulating drive torque in response to monitored vehicle operating conditions.

If the indicator lamp fails to go out after the engine is started, or comes on during the course of normal vehicle operation:

If the system was not switched off, there is a system malfunction. The vehicle remains operational, but without DSC. Please consult your BMW center for repairs.

To deactivate the system

Press the button. The indicator lamp flashes.

The illustration depicts the arrangement of the buttons if the vehicle is fully equipped. This may vary, depending on the equipment actually installed.

When the DSC is deactivated, you are operating the vehicle in the conventional drive mode.

In exceptional instances, it is effective to deactivate the system:

- ▷ when rocking the vehicle or starting off in deep snow or on loose surfaces
 - ▷ or when driving with snow chains.
- Refer also to page [110](#).

To reactivate the system

Press the button again; the indicator lamp goes out.



The laws of physics cannot be repealed, even with DSC. Any consequences arising from traction loss due to excessive vehicle speed remain the responsibility of the driver. For this reason, do not take risks by using the additional safety margin provided by the system as an excuse. ◀

For additional details concerning DSC, please refer to the chapter describing "Advanced technology" on page [163](#).

The concept

RDC monitors the tire pressures at all four wheels, even when the vehicle is moving. The system provides an alert whenever the inflation pressure drops significantly below the specified pressure in one or more tires.

In order for the system to "learn" the correct tire inflation pressure, check the inflation pressure in all tires. Refer to the table of "Tire inflation pressures" (page 28) and correct the pressures if necessary. Then activate the system.



This indicator lamp in the instrument cluster will inform you if the tire pressure is not correct.

**Activate the system**

- 1 Turn the ignition key to position 2.
- 2 Press the switch long enough for the yellow indicator lamp in the instrument cluster to light up for a few seconds.
- 3 After a few minutes driving time, RDC sets the current inflation pressure in the tires as the target values to be monitored.

You will only have to repeat this procedure following a correction of the tire inflation pressure. Otherwise, RDC functions automatically when the ignition key is in position 2, and thus operates whenever the vehicle is driven.

Loss in tire pressure

If the inflation pressure has dropped significantly over a long period of time (which is normal for any tire), the indicator lamp will come on with a yellow lamp.

This alerts you to have the tires inflated to the specified pressures as soon as possible.




If you are prompted to check the tire pressure shortly after a correction has been made, this indicates that the corrected values were not accurate. Please check the inflation pressure again and make corrections according to the inflation pressure table. Then activate the system once again. ◀

Tire Pressure Control (RDC)*

Flat tire

If there is a tire failure with loss of pressure, the indicator lamp comes on with a red lamp. In addition, an acoustic signal is sounded.

If this occurs, reduce vehicle speed immediately and stop the vehicle in a safe location. Avoid hard brake applications. Do not oversteer. Replace the wheel and flat tire.

 The space-saver spare tire* is provided for temporary use only in the event of a tire failure. It does not have RDC electronics and is not monitored. A full-size spare tire* that has the same dimensions as the tires already mounted on the vehicle is equipped with the necessary RDC electronics, and will be also be monitored once the tires have been mounted and the system activated. ◀



RDC cannot alert you to severe and sudden tire damage caused by external factors. ◀



Have the tires changed by your BMW center. Your BMW center has been trained to work with the RDC system and is equipped with the necessary special tools. ◀

System interference

The RDC system may be interrupted temporarily by other systems or devices that use the same radio frequency.

The yellow indicator lamp will come on during the malfunction.

The indicator lamp also comes on

- ▷ in the event of a system fault
- ▷ if a wheel is mounted without the appropriate electronics
- ▷ if, in addition to the spare tire*, additional wheels with RDC electronics are on board.

Please contact your BMW center for additional information.



Parking lamps



With the switch in this position, the front, rear and side vehicle lighting is switched on. For lighting on one side for parking, refer to page [83](#).

Low beam headlamps



When you switch the ignition off with the low beam headlamps on, only the parking lamps will remain on.



"Follow-me-home lighting:"
If you actuate the headlamp flasher after you have parked the vehicle and shut off the engine, the low beams will remain on for a brief period. You can also have this function deactivated. ◀

LAMPS ON warning


When you open the driver's door after turning the ignition key to position 0, an acoustic signal sounds for a few seconds to remind you that the headlamps have not been switched off.

Daytime running lamps*

If you desire, the light switch can be left in the second position:
When the ignition is switched off, the external lighting is also switched off.



Turn the rotary dial to adjust the illumination intensity.



- 1 High beams (blue indicator lamp)
- 2 Headlamp flasher (blue indicator lamp)
- 3 Parking lamps

Parking lamp, left or right

With the ignition key in position 0, engage the lever in the appropriate turn-signal position.



A green indicator lamp appears in the instrument cluster to indicate that the front fog lamps are on.



The illustration provides an example of the interior lamps when equipped with reading lamps.

The interior lamps operate automatically.

To switch the interior lamps on and off manually

Press the button briefly.

If you want the interior lamps to remain off all the time, press and hold the button for approximately 3 seconds.

To revert to normal operation, press the button briefly.

Footwell lamps*

The footwell lamps operate in the same way as the interior lamp.

84 Reading lamps*




The reading lamps are located in the front* near the interior lamp and in the rear* (illustration). They can be switched on and off with the switch adjacent to each lamp.



In order to prevent battery discharge, all of the lamps in the vehicle are switched off automatically approx. 15 minutes after the ignition key is turned to position 0. ◀

86 Automatic climate control



Automatic climate control

- 1 Air on the windshield and on the side windows
- 2 Air flow toward the upper body
The side rotary dials allow you to open and close the air supply through an infinitely-variable range, while the levers change the airflow direction. The center rotary dial controls the temperature of the air as it flows out. Refer to page [90](#)
- 3 Front footwell ventilation
There are corresponding air vents in the rear footwell as well.
- 4 Recirculated air mode/Automatic recirculated air control (AUC) [89](#)
- 5 Air supply [89](#)
- 6 Temperature [88](#)
- 7 Automatic air distribution [88](#)
- 8 Individual air distribution [88](#)
- 9 Air grill for interior temperature sensor – please keep clear and unobstructed
- 10 Display for temperature and air supply [88](#)
- 11 Defrost the windshield and side windows [89](#)
- 12 Air conditioner [89](#)
- 13 Rear window defroster [70](#), [90](#)

Tips for pleasant driving


Use the automatic system (switch on AUTO – button 7). Select an interior temperature that is comfortable for you – we recommend 70 °F (22 °C). When the outside temperature is above 42 °F (5 °C), you can also use the air conditioner (12). This will dry the air as well as preventing condensation on the window surfaces – if there are passengers with damp clothing, for example. Set the air outlets (2) so that the air flows past you and is not directed straight at you. Set the rotary dial between the air outlets (2) for the upper body to a medium position, since air that is somewhat cooler promotes driving without fatigue.


Detailed setting options are described for you in the following section.






Your vehicle is set in such a manner that, when you unlock the car with your personalized remote control, your own personalized setting of the automatic climate control is initiated. ◀

Automatic air distribution

The AUTO program assumes the adjustment of the air distribution and the air supply for you and in addition adapts the temperature to external influences (summer, winter) to meet preferences you can specify. This program maintains a comfortable in-car climate regardless of the season. Select an interior temperature that is comfortable for you – we recommend 70 °F (22 °C). The temperature selected and  AUTO for the air supply appear in display (10), refer to the overview on page 86. Open the air outlets for the upper body area. Switch on the air conditioner in warm weather. The maximum cooling capacity is achieved when you set rotary dial (3) to cold. Refer to page 90.

Individual air distribution

You can cancel the AUTO program by selecting specific distribution patterns to suit your own individual requirements.

You can direct air to flow onto the windows , toward the upper body , and into the footwell .

Temperature

The figures in the display provide a general indication of interior temperature. We recommend 70 °F (22 °C) as a comfortable setting, whether the air conditioner is operating or not. When you start the vehicle, the system ensures that the selected temperature is reached as quickly as possible. It then maintains this temperature, regardless of the season.


Set rotary dial (3; refer to "Draft-free ventilation" on page 90) to a medium setting, since air that is somewhat cooler promotes driving without fatigue. You can use this setting for mixing air to make minor comfort modifications.



The full, uncontrolled heater output is available starting at an interior temperature setting of 90 °F (32 °C). At a setting of 60 °F (16 °C), the full cooling output is available when the air conditioner is activated. ◀


Automatic climate control

Air supply


 By pressing the left or right half of the button, you can vary the air supply. By doing this, you switch off the automatic control of the air supply. Nevertheless, the automatic air distribution remains unchanged.

When you set the lowest blower speed by pressing the left half of the button, all of the displays are canceled: The blower, heating and air conditioner are switched off, and the air supply is stopped. You can reactivate the system by pressing any button of the automatic climate control.

To defrost the windshield and side windows

 This program quickly removes ice and condensation from the windshield and side windows.


Air conditioner

 The air is cooled and dehumidified and – depending on the temperature setting – rewarmed when the air conditioner system is switched on.


Depending on the weather, the windshield may fog over briefly when the engine is started.

Switch off the air conditioner at outside temperatures below approx. 42 °F (5 °C). This will help to prevent the windows from fogging up.


If the windows fog over after switching the air conditioner off, switch it back on.

 Condensation forms in the air conditioner system during operation, which then exits under the vehicle. Traces of condensed water of this kind are thus normal. ◀

Automatic recirculated air control (AUC)

 You can respond to unpleasant external odors by temporarily blocking the outside air. The system then recirculates the air already within the vehicle. By repeated actuation of the button, you can select one of three different operation modes.


- ▷ Indicator lamps off: Fresh air flows into the vehicle
- ▷ Left-hand indicator lamp on – AUC mode: The system detects pollutants in the outside air and responds by deactivating the outside air flow as required. The system then recirculates the air already within the vehicle. Depending on air quality requirements, the system automatically switches between outside air supply and recirculation of the air already within the vehicle.
- ▷ Right-hand indicator lamp on: The flow of outside air is permanently blocked. The system recirculates the air already within the vehicle.

 If the windows fog over in the recirculated air mode, switch this mode off and increase the air supply as required. ◀

Rear window defroster



When the rear window defroster is activated, the indicator lamp comes on. The rear window defroster switches off automatically. Refer to page [70](#).



Draft-free ventilation

Set the ventilation outlets for your upper body area so that it is comfortable for you:

Use rotary dials (1) to open and close the air outlets through an infinitely-variable range. You can adjust the direction of the airflow with the levers (2).

Set the outlets so that the air flows past you and is not directed straight at you.

The rotary dial (3) allows you to mix the air from the outlets for your upper body by warming or cooling the air as desired.

Microfilter, activated-charcoal filter

A microfilter removes dust and pollen from the incoming outside air. The activated-charcoal filter provides additional protection by filtering gaseous pollutants from the outside air. Your BMW center replaces the combined filter as a standard part of your scheduled maintenance. A substantial reduction in air supply indicates that the filter must be replaced before normal maintenance.

For additional details on the filter change, refer to page [155](#).

Seat heating*



The seat cushion and backrest can be heated with the ignition key in position 2.

You can call up different heating modes by repeatedly pressing the keys.

When the three indicator lamps are illuminated, the highest heating mode is activated. One lamp indicates the lowest heating mode. The temperature is regulated with a thermostat in each mode.

You can also switch the higher heating modes off directly:

Press and hold the button slightly longer.

Roller sun blind*



To actuate, press the button briefly with the ignition key in position 2.

The illustration depicts the arrangement of the buttons if the vehicle is fully equipped. This may vary, depending on the equipment actually installed.



HiFi system – harman kardon

Special acoustical effects are activated or deactivated every time you press the button.

When the system is activated, the impression of a significantly larger passenger compartment is created at all seating areas, together with an improvement of the stereo effect.

When reception is weak, the system frequently switches between stereo and mono operation. Switch the feature off if this occurs.

Glove compartment



To open


Pull the handle. The lamp comes on.


To close

Fold the cover up.

To lock


Lock with one of the master keys. A master key can also be used for unlocking.

 If you turn over only your door and ignition keys for valet parking (refer to page 32), for example, access to the glove compartment is not possible. ◀

 To prevent injury in the event of a crash, close the glove compartment immediately after use. ◀

Rechargeable flashlight*


The flashlight is located on the left-hand side of the glove compartment. It features integral overload-protection so it can be left in its holder continuously.

 Be sure that the flashlight is switched off when it is inserted into its holder. Failure to comply with this precaution could lead to overcharging and damage. ◀




Open the storage compartment in the front center armrest*: Press the button (arrow) and lift upward.

You will find additional storage areas in the front doors and in the center console above the ashtray*. Storage nets* are located on the back of the front seats.



Coin holder, cup holder

A coin holder and two cup holders are provided in the center console.



Rear center armrest*

Without through-loading system:

You will find a storage compartment and a beverage holder (for two drink containers) in the rear center armrest.

- 1 Storage compartment: Pull upward.
- 2 Beverage holder: Press to open.

94 Storage compartments



Rear center armrest*

With through-loading system:

You will find a beverage holder (for two drink containers) in the rear center armrest.

- ▷ Beverage holder: Press to open (arrow).



Storage package*

For your convenience, there are:

- ▷ two extending sockets on the center console in the rear (arrows)
- ▷ an eyeglass compartment* in the front center console above the ash-tray.



Handsfree system

On vehicles that are wired for a telephone*, the cover for the handsfree microphone is located in the headliner near the interior lamp.


For additional information concerning the cellular phone, please refer to the separate Owner's Manual.



To open

Press briefly in the direction indicated by the arrow.

To extinguish a cigarette, tap off the ash and gently press the tip into the funnel.



To empty


Open the lid and press down (arrow): You can now pull the ashtray upward for removal.

On vehicles with the nonsmoker's equipment package, the insert is removed in the same way.

96 Cigarette lighter*



Press the lighter in. Remove the lighter as soon as it retracts.

 Hold or touch the hot cigarette lighter by the knob only. Holding or touching it in other areas could result in burns.

The cigarette lighter remains operational when the ignition key has been removed. For this reason, children should never be left in the car unattended. ◀

Cigarette lighter socket

Suitable for attaching power supplies for flashlights, car vacuum cleaners, etc., up to a rating of approx. 200 watts at 12 volts. Avoid damaging the socket due to inserting plugs of different shapes or sizes.

Ashtray, rear*




To open

Push the cover open.

To empty

Press on the edge of the raised cover in the opening direction (arrow). You can now pull the ashtray upward for removal.



The rear backrest is divided into two sections (one-third and two-thirds of the width of the seat). For carrying longer objects, you can fold down either section of the backrest separately.

To unlock, pull the lever corresponding to the section (arrow).



The rear backrest section will move forward slightly when it is unlocked. Reach into the gap and pull the backrest down.



When you close the backrest, be sure that the retainer engages correctly. If it is not correctly engaged, transported cargo could enter the passenger compartment from the luggage compartment during brake applications or evasive maneuvers and endanger the vehicle occupants. ◀

The fittings at the corners of the luggage compartment provide you with a convenient means of attaching luggage nets* and flexible straps for securing suitcases and luggage.

Refer also to "Cargo loading" on page 99.

98 Ski bag*

The ski bag allows the safe and clean transport of four pairs of skis or two snowboards.

The length of the ski bag and the additional space provided in the luggage compartment make it possible to carry skis with a length of up to 6.8 feet (2.1 meters). The ski bag can only accommodate two pairs of skis with a length of 6.8 feet (2.1 meters) because of the tapered shape of the bag.




Loading


- 1 Pull the center armrest down. Loosen the trim from the upper Velcro® fastener and place it on the armrest.
- 2 Press button 1 downward and swing the cover forward.
- 3 Extend the ski bag between the front seats. The zipper provides convenient access to stored items. It may be opened to allow the ski bag to dry.
- 4 Press knob 2: The cover in the luggage compartment is unlocked.

To store the ski bag, perform the above steps in reverse sequence.

Securing the load

-  Secure the skis or other objects in the bag by tightening the strap with the buckle. ◀

Please be sure that your skis are clean before loading them into the bag. Avoid damage from sharp edges during loading.




Stowing cargo

If you are transporting a load in your BMW

- ▷ Load heavy cargo as far forward as possible – directly behind the backrests or the luggage compartment partition – and as low as possible.
- ▷ Cover sharp edges and corners.
- ▷ Do not pile objects higher than the top edge of the backrest.




- ▷ If you are transporting very heavy loads when the rear seat is not occupied, secure the outer safety belts in the opposite buckles (refer to the illustration).



Securing the load

- ▷ For small, light items, use the rubber-lined non-skid side of the floor mat or secure with a luggage compartment net* or elastic straps (refer to page 41).
- ▷ For large, heavy pieces, see your BMW center for load-securing devices*. Lashing eyes (arrow) are provided at the corners of the luggage compartment for attaching these load-securing devices.
- ▷ Comply with the information enclosed with the load-securing devices.

 Always position and secure the load correctly. If you do not, it can endanger the passengers during braking or evasive maneuvers.

Do not exceed the permissible gross vehicle weight and the permissible axle loads (refer to page 174). If you do, the operating safety of the vehicle is no longer ensured and you are in violation of the law.

Do not carry hard or heavy objects unsecured in the passenger compartment. If you do so, they may be projected through the air during braking and evasive maneuvers, thus endangering vehicle occupants. ◀

Roof-mounted luggage rack*



Anchors

Access to the anchors:
To open the cover (arrow), please use the tool included with the luggage rack system.

A special roof-rack system is available for your BMW as an optional extra. Please comply with the precautions included with the installation instructions.

Because roof racks raise the center of gravity of the car when loaded, they exercise a major effect on its handling and steering response.

You should therefore always remember not to exceed the approved roof weight, the approved gross vehicle weight or the axle weights when loading the rack. You will find the specifications under "Technical Data" on page 174.

Make sure that the load is not too heavy, and attempt to distribute it evenly.

Always load the heaviest pieces first (on the bottom). Be sure that adequate clearance is maintained for raising the sliding/tilt sunroof*, and that objects do not project into the opening path of the luggage compartment lid.

Secure the roof luggage correctly and securely to prevent it from shifting or being lost during driving (danger to following traffic).

Drive smoothly and avoid sudden acceleration or braking. Do not corner at high speeds.

The roof load increases the aerodynamic resistance. Increased fuel consumption and additional stresses on the vehicle's body result from this.



Special operating instructions:

- Break-in procedures 104
- Driving notes 104
- Catalytic converter 105
- Antilock Brake System (ABS) 106
- Disc brakes 108
- Brake system 109
- Winter operation 110
- Power steering 111
- Cellular phones 112
- Radio reception 112

Wheels and tires:

- Tire inflation pressures 113
- Tire condition 113
- Tire replacement 114
- Tire rotation 115
- Wheel and tire combinations 116
- Winter tires 117
- Snow chains 117
- Approved wheel and tire specifications 118

Under the hood:

- Hood 120
- Engine compartment 122
- Washer fluids 124
- Washer nozzles 124
- Engine oil 125
- Coolant 128
- Brake fluid 129
- Vehicle Identification Number 130

Care and maintenance:

- The BMW Maintenance System 131
- Caring for your car 132
- Airbags 137
- Vehicle storage 137

Laws and regulations:

- Technical modifications to the vehicle 138
- OBD interface socket 139

Overview**Controls and features****Operation, care and maintenance****Owner service procedures****Advanced technology****Technical data****Index**

To ensure that your vehicle provides maximum economy throughout a long service life, we request that you comply with the following recommendations:

Engine and differential

Up to 1,200 miles (2,000 km):

Drive at varying engine speeds and road speeds, but do not exceed 4,500 RPM or a road speed of 100 mph (160 km/h) during this initial period.

Do not apply full throttle and avoid pressing the accelerator beyond the kickdown point.

After 1,200 miles (2,000 km), you can gradually increase the engine speed or road speed.

Follow the same break-in procedure if either the engine or the differential is replaced in the future.

Tires

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until an initial break-in period has elapsed. For this reason, drive cautiously during the first 200 miles (300 km).

Brake system

Brake pads and disks do not attain their optimal wear patterns until after approx. 300 miles (500 km).

To break-in the separate parking brake drums, apply the parking brake lightly when coasting to a standstill (at a traffic signal, for instance), provided that traffic conditions allow you to do so.

To avoid corrosion, repeat this procedure from time to time.



The brake lamps do not come on when the parking brake is set. Vacuum for the brake system servo unit on your BMW is available only when the engine is running. When you move the car with the engine off – when towing, for example – substantially higher levels of pedal force will be required to brake the vehicle. ◀

Driving notes



Brakes: Do not drive with your foot resting on the brake pedal. Even light but consistent pedal pressure can lead to high temperatures, brake wear, and possibly to brake failure.

Aquaplaning:

Reduce your speed when you drive on wet or slushy roads. If you do not, a wedge of water can form between the tires and the road surface. This phenomenon is referred to as aquaplaning or hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface.

The ultimate results are loss of steering and braking control.

Driving through water:

Do not drive through water that is deeper than 1 foot (30 cm). If you must drive through water accumulations up to that depth, drive only at walking speed. Driving at a faster speed could cause damage to the engine, the electrical systems and the transmission.

Package tray:

Never use the rear window shelf to store heavy or bulky objects. If you do so, such objects could pose the risk of injury to vehicle occupants during braking or evasive maneuvers or in a crash.

Clothes hooks:

When suspending clothing from the hooks, be sure that they will not obstruct the driver's vision. Do not hang heavy objects on the hooks. If you do so, such objects could pose the risk of personal injury during braking or evasive maneuvers. ◀

The catalytic converter reduces harmful exhaust emissions, and is designed for use with unleaded fuel only.

Even minute quantities of lead would be enough to permanently damage both the catalytic converter and the system oxygen sensor.

To ensure efficient, trouble-free engine operation and avoid potential damage:

- ▷ Be sure to comply with the scheduled maintenance requirements.
- ▷ Fill the fuel tank well before it is empty.
- ▷ Tow-start only when the engine is cold. If you attempt to tow-start with a warm engine, unburned residual fuel in the catalytic converter could ignite and cause damage. It is better to jump-start the vehicle with outside assistance.
- ▷ Avoid other situations in which the fuel is not burned, or burns incompletely, such as engaging the starter frequently or for extended periods, or repeated start attempts in which the engine does not start (stopping and restarting an engine which is running properly does not present a problem). Never allow the engine to run with any of the spark plug cables disconnected.



Be sure to comply with the instructions above to prevent unburned fuel from reaching the catalytic converter. If you do not, the catalytic converter could respond by overheating, leading to serious damage. Extreme temperatures occur at the catalytic converter on this and every catalyst-equipped vehicle. Heat shields are installed adjacent to some sections of the exhaust system. Never remove these shields; do not apply undercoating to their surfaces. When driving, standing at idle, and parking the vehicle, take extra care to avoid contact between the exhaust system and flammable materials (grass, hay, leaves, etc.). Such contact could lead to a fire, resulting in serious personal injury and property damage. ◀

The concept

ABS enhances active safety by helping to prevent the wheels from locking under braking. This is because locked wheels are dangerous. When the front wheels slide, the driver loses steering control over the vehicle. Traction loss at the rear wheels can cause the rear end to break into an uncontrolled skid.

ABS is designed to meet two essential requirements during every brake application:

- ▷ To help provide vehicle stability
- ▷ To help maintain steering control and maneuverability – on all types of road surfaces (asphalt, concrete, mud, wet, snow, ice).

The system can achieve the shortest braking distances possible under most conditions (on straight-aways and in curves, on asphalt, ice, wet road surfaces, etc.).

Braking with ABS

The system becomes operative once the vehicle exceeds a speed of approx. 6 mph (10 km/h). Below approx. 3 mph (6 km/h), it is once again deactivated. This means that the wheels can lock in the final phase of a panic stop – a factor of no significance in actual use.

If you are in a situation that requires full braking, you will exploit the full benefits of the ABS system if you apply maximum brake pressure ("panic stop"). Since the vehicle maintains steering responsiveness, you can avoid possible obstacles with a minimum of steering effort, despite the full brake application.

The ABS system closed-loop control circuit cycles in fractions of a second. A pulsation at the brake pedal indicates to the driver that ABS is active, that is, that the vehicle is within its maximum braking range. In addition, a pulsation – a result of the control function cycles – indicates to the driver that vehicle speed should be reduced to adapt to road surface conditions when there is reduced traction and grip between tires and road surface (slippery road surface).

On road surfaces that have a loose surface layer on a firm base with good traction (on gravel or snow, for exam-

ple), or when snow chains are mounted, braking distances may be longer than with locked wheels. However, ABS continues to provide enhanced vehicle stability and steering response under these conditions.

Information for your safety

Not even ABS can suspend the laws of physics. ABS cannot prevent the consequences of brake applications with inadequate clearances for safety between vehicles, when exceeding the speed limit in curves, or the risks involved when aquaplaning occurs. Responsibility for these types of situations remains in the hands (and at the feet) of the driver. You should never allow the added safety of ABS to lull you into a false sense of security, or mislead you into taking increased risks that could affect your own safety and that of others.




Do not make any modifications to the ABS system.


Service procedures on ABS are to be performed by authorized technicians only. ◀


Antilock Brake System (ABS)/ Cornering Brake Control (CBC)



CBC is an advanced engineering development of ABS. When braking during cornering with high lateral acceleration, or when braking during a lane change, vehicle stability is improved and the steering response is enhanced.

In the event of a fault

 If the ABS in the instrument cluster lights up, refer to page 22. The brake system then reverts to conventional operation as on vehicles without ABS. However, have the brake system checked by your BMW center as soon as possible. To prevent undetected defects and cumulative faults from adversely affecting the brake system, refer any problems to your BMW center at the earliest opportunity.

 ABS warning lamp for Canadian models.

 If the brake warning lamp comes on together with the indicator lamps for ABS and DSC (refer to page 21), the entire ABS, CBC and DSC control system has failed. Continue driving cautiously and defensively. Avoid full brake applications.

  This could cause the vehicle to lose stability and you might no longer be able to control it. Have the system checked as soon as possible by your BMW center.




CBC, ABS and DSC indicator and warning lamps for Canadian models.

Disc brakes furnish optimum deceleration and braking control and greater fade resistance under heavy use.

When the vehicle is driven only occasionally, during extended periods when the vehicle is not used at all, and in operating conditions where brake applications are less frequent, there is an increased tendency for corrosion of the rotors and accumulation of contamination on the brake pads. This occurs because the minimal pressure that must be exerted by the pads to clean the rotors by brake applications is not reached.

If the brake rotors are corroded, they will tend to respond to braking with a pulsating effect that even extended brake applications will fail to cure.

 For your own safety: Use only brake pads that BMW has approved for your particular vehicle model. BMW cannot evaluate non-approved brake pads to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are installed. ◀

Driving notes

When driving in wet conditions and in heavy rain, it is effective to apply light pressure to the brakes every few miles or kilometers. Be aware of traffic conditions to ensure that this maneuver does not endanger other road users. The heat that is generated by the brake applications helps to dry the brake pads and rotors.

Maximum braking force is obtained while the wheels are not locked, but rather when they are still barely turning immediately prior to locking. ABS maintains this state automatically. If the ABS fails, you should revert to the staggered braking technique described above on page 110.

Long or steep mountain descents do not necessarily lead to reduced braking efficiency if you drive downhill with the transmission in a gear that allows minimal brake applications (or, with an automatic transmission, in an appropriate lower range).

You can further increase the engine's braking effect by selecting a lower gear, downshifting as far as first gear or placing the selector lever in position 1.

Should engine braking prove inadequate, you should still avoid extended, continuous braking. Instead of maintaining low to moderate pressure over an extended period of time, you should decelerate by applying more substantial pressure to the brake pedal (watch for following traffic), releasing the pedal, and then repeating the application (staggered braking). The cooling phases between active braking intervals prevent the brakes from overheating, thus ensuring that full braking capacity remains available at all times.



Do not coast with the clutch depressed or with the shift lever or selector lever in neutral. Do not drive with the engine shut off. The engine provides no braking effect when the clutch is depressed or the transmission is in neutral, and there is no power-assist for braking or steering when the engine is not running. Do not allow floor mats, carpets or any other objects to protrude into the area around the brake pedal, the clutch or the accelerator which could obstruct their freedom of movement. ◀

Brake system

Brake fluid level



If the brake warning lamp comes on and the parking brake has been released:

The brake fluid level is too low in the reservoir (refer to page 129).

If the brake fluid level is too low and brake pedal travel has become noticeably longer, there may be a defect in one of the hydraulic circuits of the brake system.



Brake warning lamp for Canadian models.



Proceed to the nearest BMW center. Higher brake application pressure may be necessary under these conditions, and brake pedal travel may be significantly longer. Please remember to adapt your driving style accordingly. ◀

Brake pads



If the warning lamp for the brake pads lights up:

The brake pads have reached their minimum pad thickness. Proceed to the nearest BMW center as soon as possible to have the pads replaced.



For your own safety: Use only brake pads that BMW has approved for your particular vehicle model. BMW cannot evaluate non-approved brake pads to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are installed. ◀

The onset of winter is often accompanied by rapid changes in weather. Adaptations in driving style should be accompanied by preparations on the vehicle itself to ensure that your progress through the winter remains safe and trouble-free.

Coolant

Be sure that the coolant mixture contains the year-round ratio of 50:50 water and extended-duty antifreeze/corrosion protection. This mixture provides protection against freezing down to approx. - 34 °F (- 37 °C). Replace the coolant every four years.

Locks

BMW door lock deicer can be used to free them if frozen. This deicer also contains lubricant. After its use, treatment with BMW lock barrel grease is recommended.

Rubber seals and components

To prevent the weather-stripping from freezing, apply a spray-on rubber treatment or silicone spray to the door, hood and luggage compartment lid seals.

Snow chains

BMW snow chains* can be mounted on both summer and winter tires. Mount them in pairs on the rear wheels only and comply with the manufacturer's safety precautions. Do not exceed a maximum speed of 30 mph (50 km/h). For best performance, deactivate the DSC when snow chains are mounted. Refer to page 79.

Starting off

When starting from a full stop in deep snow or for "rocking" the vehicle to free it, we recommend that you deactivate the DSC system. Refer to page 79.

Driving on low-traction road surfaces

Use smooth, gentle pressure to control the accelerator pedal. Avoid excessive engine speeds and shift to the next higher gear at an early point. On down-grades or slopes, shift down to the next lower gear at an early point. Maintain an adequate distance between yourself and the car ahead.

Brakes

Winter road conditions substantially reduce the traction available between the tires and the road surface. Remember that braking distances will be significantly longer as a result.

ABS is intended to prevent the wheels from locking during brake applications, thus helping to maintain vehicle stability and steering response.

If the ABS does not respond in a critical braking situation and the wheels lock: Reduce the pressure on the brake pedal until the wheels just start to roll again while still maintaining enough force to continue braking.

Following that, increase pedal pressure again. Reduce the pressure as the wheels lock, then reapply pressure. Repeat this procedure. This type of staggered braking will reduce the braking distance, and the vehicle still remains responsive to steering. It allows you to steer around hazards once you have reduced the pressure on the brake pedal.



A full range of car care products is available from your BMW center. ◀

Winter operation



Do not shift down on slick road surfaces. Doing so could cause the rear wheels to lose traction and skid, resulting in a loss of vehicle control. ◀



Depress the clutch during hard braking on road surfaces that provide only poor or uneven traction. ◀

Skid control

Depress the clutch and release the accelerator pedal, or place the selector lever of the automatic transmission into the "Neutral" position. Countersteer carefully and attempt to regain control of the vehicle.

Parking

Engage 1st or reverse gear. If your car is equipped with an automatic transmission, place the selector lever in Park. On vehicles with manual transmission, also apply the parking brake when parking on inclined surfaces. In order to prevent the parking brake linings from locking due to frost or corrosion, dry them by gently applying the parking brake as the vehicle is coming to a stop. Make sure that following traffic is not endangered.



The brake lamps do not light up when the parking brake is applied. ◀

Power steering

High steering effort:

Contact an BMW center immediately to have this system inspected.



If the power steering fails, increased effort will be required to steer the vehicle. ◀

Mobile communications systems (cellular phone, radio, etc.) are only allowed a power output of up to 10 watts. Mobile communications devices not specifically designed for use in your car may trigger malfunctions while operating your vehicle. BMW can neither test nor assume responsibility for every individual product being offered on the market. We recommend that you consult your BMW center before purchasing any device of this kind.

To ensure that your BMW continues to provide reliable and trouble-free operation, do not use a cellular phone or other radio device with an antenna located inside the passenger compartment or an antenna that is not mounted on the outside of the vehicle.



Before loading the vehicle on a car-carrier train or driving it through a car-wash, remove the antenna. ◀

Radio reception

The reception and sound quality obtained from mobile radios varies according to a variety of factors, including the broadcast range of the transmitter and the directional orientation of the antenna. Interference factors such as high-tension power lines, buildings and natural obstructions can all lead to unavoidable reception interference, regardless of how well the vehicle's sound system is operating.

Climatic factors such as intense solar radiation, fog, rain and snow can also interfere with reception.

Car telephones or cellular phones not approved by BMW can also cause interference in the radio during a telephone call. This phenomenon assumes the form of a low-pitched hum emanating from the speaker system.

Please refer to the supplementary operating instructions provided with your sound system for detailed information on its use.


Tire inflation pressures

Information for your safety

The factory-approved radial tires are matched to the car and have been selected to provide optimum safety and driving comfort on your car.

It is not merely the tire's service life, but also driving comfort and – above all else – driving safety that depend on the condition of the tires and the maintenance of the specified tire pressure.

Incorrect inflation pressure is a frequent cause of tire damage. It also significantly influences the roadholding ability of your BMW.

 Check tire inflation pressures regularly – include the space-saver spare tire or spare tire – at least twice a month and before beginning a longer trip. If this is not done, incorrect tire pressures can cause driving instability and tire damage, ultimately resulting in an accident. ◀

Tire condition



Tire tread – Tire damage

Inspect your tires frequently for tread wear, signs of damage and for foreign objects lodged in the tread. Check the tread depth.

The tread depth should not be any shallower than 0.12 inches (3 mm). Below this tread depth, there is a significant risk of aquaplaning, even at relatively moderate speeds and with only small amounts of water on the road.

We recommend that you always replace the tires once the tread wears to 0.12 inches (3 mm). If you continue to use the tires, wear indicators appear in the tread at 0.063 inches (1.6 mm).



Do not drive on a deflated (flat) tire. A flat tire greatly impairs steering and braking response, and can lead to complete loss of control over the vehicle.

Avoid overloading the vehicle so that the permitted load on the tires is not exceeded. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. You could have a blowout as a result.

Unusual vibrations encountered during normal vehicle operation can indicate tire failure or some other vehicle defect.

This is also true for irregularities in the vehicle's handling characteristics, such as a pronounced tendency to pull to the left or right. Should this occur, respond by immediately reducing your speed.

Proceed carefully to the nearest BMW center or professional tire center, or have the vehicle towed in to have it and its tires inspected.

Tire damage (up to and including blowouts) can endanger the lives of both the vehicle occupants and other road users. ◀


To maintain good handling and vehicle response, use only tires of a single tread configuration from a single manufacturer. BMW tests and approves wheel/tire combinations. Refer to page 118.

DOT Quality Grades

Treadwear

Traction AA A B C

Temperature A B C

 All passenger car tires must conform to Federal Safety Requirements in addition to these grades. ◀

Treadwear


The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and one-half (1 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The traction grades, from highest to lowest, are AA, A, B and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.


 The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics. ◀

Temperature

The temperature grades are A (the highest), B and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal

Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

 The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure. ◀

Uniform Tire Quality Grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear 200 Traction AA
Temperature A

Tire replacement



Do not use retreaded tires. Driving safety may be impaired by their use. This is due to the possible variations in casing structures and, in some cases, to their extreme age, factors that can lead to a decrease in their durability. ◀

Tire age

The date on which the tire was manufactured is indicated by the code on the sidewall:

DOT ... 329 indicates that the tire was manufactured in Week 32 of 1999.

BMW recommends the replacement of all tires when the tires are no more than 6 years old, even if a tire life of 10 years is possible.

Spare tires over 6 years old should be used only in case of emergency. A tire in this condition should be replaced by a new tire immediately, and should not be mounted together with new tires.

Tire rotation

Between the axles

The tread wear patterns at the front end differ from those at the rear – the actual patterns will vary according to individual driving conditions. In the interests of safety and maintaining optimal handling characteristics, tire rotation is not recommended.

If a proposed interaxle rotation of tires is based on economic considerations, one should consider whether the costs for the rotation are likely to be recaptured by any increase in the service life of the tires that might be realized. In principle, interaxle rotation should be performed in short intervals, with a maximum of 3,000 miles (5,000 km). Consult your BMW center for more information.

Should you decide to rotate the tires, it is essential to comply with the following: Rotate tires on the same side only, since braking characteristics and road grip could otherwise be adversely affected.

Following rotation, the tire inflation pressure should always be corrected.



If different tire sizes are mounted on the front and rear axles (refer to page 118), the wheels may not be rotated from one axle to the other. ◀

The right choice

Use only BMW-approved tires. Refer to page 118.

Due to the high speeds this vehicle can reach, the use of specific brands, specifications and sizes is mandatory. Consult any BMW center for details. Comply with local/national regulations.



The correct wheel-tire combination affects different systems such as ABS, ATC and DSC. The function of these systems is impaired if improper wheel-tire combinations are used.

For this reason, use only tires of the same brand and tread pattern. In the event of a flat tire, for example, remount the approved wheel-tire combination as soon as possible. ◀

Codes on tires and wheels

The tire codes will aid you in selecting the correct tire.

The codes on radial tires:

Example: 205/60 R 15 91 W

Nominal width in mm _____

Aspect ratio in % _____

Radial tire ID code _____

Rim diameter in inches _____

Load rating (not on ZR tires) _____

Speed rating (before R on ZR tires) _____

The speed rating indicates the approved maximum speed for the tire.

Summer tires:

S = up to 112 mph (180 km/h)
 T = up to 118 mph (190 km/h)
 H = up to 130 mph (210 km/h)
 V = up to 150 mph (240 km/h)
 W = up to 167 mph (270 km/h)
 Y = above 167 mph (270 km/h)
 ZR = above 150 mph (240 km/h)

Winter tires:

Q M+S = up to 100 mph (160 km/h)
 T M+S = up to 118 mph (190 km/h)
 H M+S = up to 130 mph (210 km/h)

Codes stamped on light-alloy wheels:

Example: 7 J x 15 H 2

Rim width in inches _____

Code letter for flange type _____

Symbol for full-drop center rim _____

Rim diameter in inches _____

Hump on the 2 rim shoulders _____

Protect tire valve from dirt by using screw-on valve stem caps. Dirt in the valves frequently leads to slow leaks.

Winter tires

Choosing the right tire

BMW recommends winter tires (M+S radial tires) for driving in adverse winter road conditions. Although all-season M+S tires provide better winter traction than standard summer tires with H, V, W, Y and ZR speed ratings, they generally fail to provide the same levels of performance as standard snow tires in winter driving.

In the interest of safe tracking and steering response, install winter tires made by the same manufacturer having the same tread configuration on all four wheels.

Mount only winter tires approved by BMW. Any BMW center will be glad to provide you with information on the best winter tires for your particular driving conditions.



Never exceed the maximum speed for which the tires are rated.

Unprofessional attempts by laymen to service tires can lead to damage and accidents.

Have this work performed by skilled professionals only. Any BMW center has the required technical knowledge and the proper equipment and will be happy to assist you. ◀

Tire condition, tire pressure

Winter tires display a perceptible loss in their ability to cope with winter driving conditions once the tread wears to below 0.16 inches (4 mm), and should thus be replaced.

Comply with the specified tire inflation pressures – and be sure to have the wheel and tire assemblies balanced every time you change the tires.

Storage

Always store tires in a cool, dry place. Store them away from light whenever possible. Protect the tires against contact with oil, grease and fuel.

Snow chains*

The use of narrow-link BMW snow chains on summer or winter tires is approved only in pairs and only on the rear wheels. Comply with all manufacturer's safety precautions when mounting the chains.

118 Approved wheel and tire specifications

| Tire specifications | Steel rim (wheel rim) | Light-alloy wheel |
|-------------------------------|-----------------------|-------------------|
| BMW 323i | | |
| All-Season | | |
| 195/65 R 15 91 H | - | 6.5Jx15 |
| Summer tires | | |
| 195/65 R 15 91 H | - | 6.5Jx15 |
| 205/60 R 15 91 H | - | 6.5Jx15 7Jx15 |
| 205/55 R 16 91 H | - | 7Jx16 |
| 225/50 R 16 92 W | | |
| 225/50 ZR 16 | | |
| 225/45 R 17 91 W | - | 8Jx17 |
| Front: 225/45 ZR 17 | - | 7.5Jx17 |
| Rear: 245/40 ZR 17 | - | 8.5Jx17 |
| Winter tires | | |
| 195/65 R 15 91 Q M+S | 6.5Jx15 | 6.5Jx15 |
| 205/60 R 15 91 Q M+S | 6.5Jx15 | 6.5Jx15 7Jx15 |
| 205/55 R 16 91 Q M + S | 7Jx16 | 7Jx16 |
| 225/50 R 16 92 Q M + S | | |
| 225/45 R 17 91 Q M + S | - | 8Jx17 |
| Space-saver spare tire | | |
| T 125/90 R 15 96 M | 3.5Bx15 | - |
| T 125/90 R 16 98 M | 3.5Bx16 | - |

Comply with the specifications for tires and wheels in the vehicle's manuals. If you install tire sizes not approved by the manufacturer, an entry in the vehicle documents may be necessary.

Snow chains*

You cannot mount snow chains with the following tires:

225/50 R 16 92 W
 225/50 ZR 16
 225/45 ZR 17
 245/40 ZR 17
 225/45 R 17 91 W
 225/50 R 16 92 Q/T/H
 225/45 R 17 91 Q/T/H

Mixed tires

For details concerning tire manufacturers for mixed tires, refer to the original-equipment specifications.

Approved wheel and tire specifications

| Tire specifications | Steel rim (wheel rim) | Light-alloy wheel |
|------------------------|-----------------------|-------------------|
| BMW 328i | | |
| All-Season | | |
| 205/55 R 16 91 H | - | 7Jx16 |
| Summer tires | | |
| 205/55 R 16 91 H | - | 7Jx16 |
| 225/50 R 16 92 H | | |
| 225/50 ZR 16 | | |
| 225/45 R 17 91 H | - | 8Jx17 |
| Front: 225/45 ZR 17 | - | 7.5Jx17 |
| Rear: 245/40 ZR 17 | - | 8.5Jx17 |
| Winter tires | | |
| 205/55 R 16 91 Q M + S | 7Jx16 | 7Jx16 |
| 225/50 R 16 92 Q M + S | | |
| 225/45 R 17 91 Q M + S | - | 8Jx17 |
| Space-saver spare tire | | |
| T 125/90 R 16 98 M | 3.5Bx16 | - |

Comply with the specifications for tires and wheels in the vehicle's manuals. If you install tire sizes not approved by the manufacturer, an entry in the vehicle documents may be necessary.


Snow chains*

You cannot mount snow chains with the following tires:

225/50 R 16 92 W
 225/50 ZR 16
 225/45 ZR 17
 245/40 ZR 17
 225/45 R 17 91 W
 225/50 R 16 92 Q/T/H
 225/45 R 17 91 Q/T/H

Mixed tires

For details concerning tire manufacturers for mixed tires, refer to the original-equipment specifications.

 Do not work on your vehicle without appropriate skills. Always switch off the engine and allow it to cool down before working in the engine compartment. Always disconnect the battery before working on any electrical systems or equipment, especially when these are located within the engine compartment. Comply with all applicable instructions and warnings. Failure to work in an informed, professional manner when servicing components and materials constitutes a safety hazard for vehicle occupants and other road users. If you are not familiar with the guidelines, please have the operations performed by your BMW center. ◀

**To unlock**

Pull the lever located under the left-hand side of the instrument panel.

**To open**

Pull the release handle and open the hood.




To close

Allow the hood to drop from a height of about 12 inches (30 cm) so that it audibly engages.




To avoid injuries, be sure that the travel path of the hood is clear when it is closed, as with all closing procedures. If it is determined that the hood is not completely closed while driving, stop immediately and close it securely. ◀

122 Engine compartment



Engine compartment


- 1 Brake fluid reservoir [129](#)
- 2 Engine oil dipstick [125](#)
- 3 Coolant expansion tank [128](#)
- 4 Engine oil filler neck [125](#)
- 5 Reservoir for the windshield and headlamp washer system* [124](#)
- 6 Auxiliary terminal for jump starting [157](#)




Headlamp* and windshield washer system

Filling capacity: approx. 5.6 US quarts (5.3 liters).

Fill with water and – if required – with a washer antifreeze (according to manufacturer's recommendations).

 We recommend that you mix the washer fluid before adding it to the reservoir. ◀

 Antifreeze agent for the washer systems is inflammable. For this reason, keep it away from sources of flame and store it in its original container. Store it so that it is inaccessible to children. Comply with the instructions on the containers. ◀




Washer nozzles

Windshield washer

The spray from the nozzles should be directed so as to ensure effective cleaning, even at high speeds. Use a needle to adjust the nozzles as required, or have them adjusted by your BMW center.

Headlamp washer system

Have this system adjusted by your BMW center as required.



Checking the oil level


- 1 Park the vehicle on a level surface.
- 2 Shut the engine off after it has reached normal operating temperature.
- 3 After approx. 5 minutes, pull the dipstick out and wipe it off with a clean lint-free cloth, paper towel, or similar material.
- 4 Push the dipstick all the way into the guide tube and pull it out again.
- 5 The oil level should be between the two graduations on the dipstick.

As with fuel economy, oil consumption is directly influenced by your driving style and vehicle operating conditions.

The space between the two marks on the dipstick corresponds to approx. 1.1 US quarts (1 liter). Do not fill beyond the upper mark on the dipstick. Excess oil will damage the engine.

To add oil

Wait until the level has dropped to just above the lower mark before adding oil. However, never let the oil drop below the lower mark.

 BMW engines are designed to operate without oil additives; the use of additives could lead to damage in some cases. This also applies for the manual transmission, automatic transmission, differential and the power steering system. ◀

Specified engine oils

The quality of the engine oil is extremely important for the function and life of an engine. Based on extensive testing, BMW has approved only certain types of engine oils.

Use only approved "BMW High Performance Synthetic Oil."

If you are unable to obtain "BMW High Performance Synthetic Oil," you may use small volumes of other approved synthetic oils for topping up between oil changes. Use only oils with the specification API SH or higher.



Ask your BMW center for details concerning the specific "BMW High Performance Synthetic Oil" or other synthetic oils that have been approved. ◀

You can also call BMW of North America at 1-800-831-1117 or visit this website: www.bmwusa.com to obtain this information.


Viscosity ratings

Viscosity is the oil flow rating as established in SAE classes.

The selection of the correct SAE class depends on the climatic conditions in the area where you drive your BMW.

BMW recommends the use of oils in SAE classes SAE 0W-X or SAE 5W-X ("X" stands for a typical value such as 30, 40, or 50).

These oils may be used for driving in all ambient temperatures.



Engine oil



Always comply with all environmental protection guidelines and regulations when disposing of used oil. ◀


Recommendation: Have the oil changed by your BMW center only.



Continuous exposure to used oil has caused cancer in laboratory testing.

For this reason, thoroughly wash any areas of skin that come into contact with oil using soap and water.

Always store oils, grease and similar materials so that they are inaccessible to children. Comply with warning labels and information on containers. ◀

 Do not add coolant to the cooling system when the engine is hot. If you attempt to do so, escaping coolant can cause burns.

To avoid the possibility of damage later on, never use anything other than factory-approved, nitrite and amino-free extended-duty antifreeze with corrosion inhibitor. Your BMW center is familiar with the official specifications.

Antifreeze and anticorrosion agents are hazardous to health. You should always store them in their original container and in a location that is inaccessible to children. Extended-duty antifreeze with corrosion inhibitor contains ethylene glycol, a flammable substance. For this reason, do not spill antifreeze with corrosion inhibitor on hot engine parts. It could ignite and cause serious burns. ◀



Comply with the applicable environmental laws regulating the disposal of extended-duty antifreeze with corrosion inhibitor. ◀



Checking coolant level

Correct coolant level when the engine is cold (approx. 68 °F or 20 °C):

Unscrew the cap from the expansion tank.

The coolant level is correct when the end of the red float is aligned with the upper edge of the filler opening (refer to the arrow in the illustration), or max. 0.8 in (2 cm) higher, that is up to the second mark on the float (see also the schematic diagram next to the filler opening).

Add coolant

Wait until the engine cools before removing the cap from the expansion tank. The needle of the coolant gauge in the instrument cluster must be located in the blue zone. If it is not, there is a danger of scalding.

- 1 Turn the cap slightly counterclockwise in order to allow accumulated pressure to escape. Then open.
- 2 If the coolant is low, slowly add coolant until the correct level is reached – do not overfill.

The coolant is a mixture of water and extended-duty antifreeze with corrosion inhibitor. Always maintain the prescribed all-season 50:50 mixture ratio for year-round protection against internal corrosion. No other additives are required.

Replace the coolant every four years.

Brake fluid



If the brake warning lamp comes on and the parking brake has been released:

Check the brake fluid level and if necessary, fill it back up to the top mark.

For adding brake fluid or for determining and correcting the cause of brake fluid loss, consult your BMW center. Your BMW center is familiar with the specifications for factory-approved brake fluids (DOT 4).

Brake fluid loss can result in extended pedal travel. Comply with the information provided on page [109](#).



Brake fluid is hygroscopic, that is, it absorbs moisture from the air over time.

In order to ensure the safety and reliability of the brake system, have the brake fluid changed every two years by a BMW center. Refer also to page [154](#) and to the Service and Warranty Information Booklet (US models) or Warranty and Service Guide Booklet (Canadian models).


Brake fluid is toxic and damages the vehicle's paint. You should always store it in its original container and in a location that is inaccessible to children.

Do not spill the fluid and do not fill the brake fluid reservoir beyond the "MAX" mark. The brake fluid could ignite upon contact with hot engine parts and cause serious burns. ◀



Comply with the applicable environmental laws regulating the disposal of brake fluid. ◀

130 Vehicle Identification Number



In the engine compartment, on the right-hand strut dome (arrow).



The BMW Maintenance System has been designed as a reliable means of providing maximum driving and operating safety – and as cost-effectively as possible for you. Technical innovations have made it possible to reduce maintenance costs significantly compared to earlier models.

Please keep in mind that regular maintenance is not only necessary for the safety of your vehicle, but also plays a significant role in maintaining the resale value of the vehicle.

Service Interval Display

Advanced technology is employed to calculate the optimal maintenance intervals. These are then indicated in the Service Interval Display. While conventional systems rely on distance traveled alone to determine when service is due, the BMW Maintenance System has for years considered the actual conditions under which the vehicle operates, because miles can be traveled in many different ways.

From the point of view of maintenance, 62,000 miles (100,000 km) accumulated in short-distance urban driving are not the equivalent of the same distance covered at moderate speeds in long-distance highway travel.


The BMW Maintenance System includes the Engine Oil Service and Inspections I and II.

Determining the maintenance intervals according to the actual use of the car covers every kind of operating situation. Minimal use drivers – those who drive significantly less than 6,000 miles (10,000 km) per year – should nevertheless have the oil changed at least every two years, since engine oil ages regardless of use.

Service and Warranty Information Booklet (US models) / Warranty and Service Guide Booklet (Canadian models)

Please refer to the Service and Warranty Information Booklet (US models) or Warranty and Service Guide Booklet (Canadian models) for additional information on maintenance intervals and procedures.

As a precaution against rust, it might be a good idea to have the body checked for damage from rocks or gravel at the same time, depending upon operating conditions.

 Have your BMW center perform maintenance and repair. Your BMW center is always informed on the latest maintenance work and repair techniques and equipped with the required special tools. In addition, checking parts known from experience to be subject to wear is a permanent part of the maintenance specifications. Be sure that all maintenance work is confirmed in the Service and Warranty Information Booklet (US models) or Warranty and Service Guide Booklet (Canadian models). These entries are your verification for the regular maintenance of your vehicle and are required for the performance of warranty repairs. ◀

Washing your car

You can have your BMW washed in an automatic car wash, even when it is new. Car wash systems that do not employ brushes are preferable.


Wipe away tough dirt and loosen and remove dead insects before washing the car.

In order to avoid spots, do not wash the vehicle when the hood is warm, or during or immediately after exposure to strong sunlight.

When using an automatic car wash, be sure that:


- ▷ The car wash system is suited for the dimensions of your vehicle.
- ▷ No damage will occur on vehicles with attached body accessories (such as spoilers or antennas). Consult the car wash operator if necessary.
- ▷ The wheels and tires of your vehicle cannot be damaged by the conveyance devices of the car wash system.
- ▷ The vehicle is cleaned with minimum brush pressure, and that ample water is available for washing and rinsing.

Vehicles with rain sensor*:
Clean the windshield regularly. Wax from automatic car washes or insects can cause malfunctions in the function of the rain sensor*.

 Turn the rain sensor* off (refer to page 69) when passing through an automatic car wash. Failure to do so could result in damage caused by unintended wiper activation. ◀


Parts of the car that are inaccessible to the automatic washer – such as door sills, door and hood edges, etc. – should be cleaned by hand.

In the winter months, it is especially important to be sure that the car is washed on a regular basis. Large quantities of dirt and road salt are difficult to remove, and they also cause damage to the vehicle.

 If spray wands or high-pressure washers are used, be sure to maintain an adequate distance between the spray source and the vehicle's surface. Inadequate distance and excessive pressure can damage or weaken the finish, making it more susceptible to subsequent attack. In addition, moisture could penetrate to vehicle components, leading to long-term damage. ◀

 When cleaning the headlamps, please observe the following:

- ▷ Do not clean by wiping with a dry cloth (this causes scratches). Never use abrasives or strong solvents.
- ▷ Remove dirt and contamination (such as insects) by soaking with BMW Car Shampoo and then rinsing with plenty of water.
- ▷ Always use a deicer spray to remove accumulated ice and snow – never use a scraper. ◀

 After washing the car, apply the brakes briefly to dry them. Braking efficiency might otherwise be reduced by the moisture and the brake rotors could also be corroded. ◀

Caring for your car

Exterior finish

To provide effective corrosion protection, multilayer paintwork is applied at the factory. Cathoretic immersion priming techniques are supplemented using special body-cavity protectants, with the application of specially-developed and extensively tested materials. A layer of flexible PVC is first applied to the undercarriage. Following this, a comprehensive undercoating treatment with a wax-based protectant is applied. Regular maintenance makes an important contribution to maintaining the safety and value of your vehicle.

Increasing awareness of the effects of harmful environmental factors on vehicle finishes have urged paint and vehicle manufacturers to initiate ongoing programs designed to further improve the durability of their finishes. Despite this, environmental factors that occur locally or regionally can have negative effects on the finish of your vehicle. These should guide you in determining the frequency and extent of your efforts to maintain the vehicle finish.

Depending upon material and type of impact (perforation of paint layer), physical stresses from sand, road salt,

gravel, etc., can cause corrosion to start extending beneath the finish, starting at the point of impact.

Road dirt, tar spots, dead insects, animal droppings (strong alkali effect) and tree excretions (resins and pollen) all contain substances capable of causing damage when allowed to remain on the finish of your vehicle for any period of time. This includes spots, etching, flaking, and separations in the top coat.

In industrial areas, deposits of flue dust, lime, oily soot, precipitation containing sulfur-dioxide (acid rain) and other environmental pollutants will damage the car's finish unless adequate care is provided – even though this is generally limited to the outside horizontal surfaces.

In coastal regions, high levels of atmospheric salt and humidity promote corrosion.


In tropical zones, temperatures of over 105 °F (40 °C) in the shade prevail, in addition to heavy ultraviolet radiation and high humidity. Under those conditions, light paints can reach temperatures up to 175 °F (80 °C) and dark paints up to 250 °F (120 °C).

Caring for the vehicle finish

Regular washing is a preventive measure against long-term effects from substances that are harmful to the vehicle's finish, especially if you drive your vehicle in areas with high levels of air pollution or aggressive natural substances (tree resins, pollen).

Nevertheless, you should immediately remove especially aggressive substances. Failure to do so can lead to changes in the paint's chemical structure or to discoloration. Gasoline spilled during refueling, oil, grease and brake fluid should always be cleaned away immediately, as should bird droppings.

Any contamination remaining on the surface of the vehicle will be especially conspicuous after washing. Use cleaning fluid or alcohol with a clean cloth or cotton pad to remove. Remove tar spots with tar remover. After cleaning, the affected areas should be waxed to ensure continued protection.

 Use cleaning and car-care products that you can obtain at your BMW center. ◀

Waxing your car

Protect the finish using carnauba or synthetic-based waxes only.

The best way to determine when the finish needs to be waxed is by noting when water stops beading on the surface.

You can use a glass cleaner to remove any wax or silicone that may have been left on the windows during waxing.



Use cleaning and car-care products that you can obtain at your BMW center. ◀

Paint damage

You can touch up small areas of paint damage with a BMW spray paint or a BMW touchup stick.

The paint color code for your car is provided on a sticker located next to the type plate and on the first page of your Service and Warranty Information Booklet (US models) or Warranty and Service Guide Booklet (Canadian models).

Damage caused by flying stones, scratches, etc., must be touched up without delay to prevent rust from forming.

If corrosion has started to form in an area with paint damage, remove all rust and clean the area. Then prime the area with a BMW Primer Stick. Finally, apply the finish coat. Wait a few days, then polish the repaired area. Finish by applying a wax preservative.

More extensive paint damage should be professionally repaired in accordance with the manufacturer's instructions. Your BMW center uses original BMW finish materials in accordance with official repair procedures.

Caring for other vehicle components and materials

Light-alloy wheels should be treated with alloy wheel cleaner, especially during the winter months. However, do not use aggressive products containing acids, strong alkalis or abrasives. Do not use steam cleaners operating at temperatures above 140 °F (60 °C). Follow the manufacturer's instructions.

If your vehicle has chrome parts* such as the window frames and door handles, clean these parts carefully with ample clean water and a shampoo supplement if desired, especially if they have an accumulation of road salt. Use chrome polish as an additional treatment.


You can use window and glass cleaner to clean inside window surfaces and mirrors without smearing and streaking. Never use polishing pastes or abrasive (quartz) cleansers on mirror lenses.

Caring for your car

Plastic components, vinyl upholstery, headliners, lamp lenses, the clear cover of the instrument panel and components with a sprayed dull black surface can be cleaned with water (add plastic shampoo as required). Do not allow moisture to soak through the seats or headliner. Never use solvents such as lacquer thinner, heavy-duty grease remover, fuels, or similar substances.

Rubber components should be cleaned with water only; a rubber treatment or silicone spray may also be applied.

Clean the wiper blades with soapy water. The wiper blades should be replaced twice a year – before and after the cold season. This is especially important for vehicles with a rain sensor*.


 Use only wiper blades approved by BMW. ◀

Do not remove safety belts to clean them. Clean them with mild soapy water only. Do not use chemicals or dry cleaners to clean safety belts, since this could damage the belt fabric.

After cleaning, never allow the inertia reel to retract the belts until they are completely dry. Dirty safety belts prevent the inertia reel mechanism from retracting the strap properly, and thus constitute a safety hazard.

Heavily soiled floor carpets and mats* can be cleaned with an interior cleaner. The floor mats can be removed from the vehicle for cleaning.

Use only a damp cloth to clean trim panels made of real wood* and other parts constructed of real wood*. Follow up by drying with a soft cloth.

 Use cleaning and car-care products that you can obtain at your BMW center. ◀


Care of upholstery materials

Depressions in the upholstery that result from everyday use can be brushed smooth by brushing against the nap with a lightly dampened brush.

The tendency of the pile to lie in a particular direction on velour upholstery is not a quality defect. Just as with home textiles or clothing, this cannot be avoided.

Lint on upholstery materials, rubbed-in fabric or suede residues can be removed with a lint brush or Velcro® brush. A cleaning glove is available for especially "stubborn" lint. Stains and fairly large areas of dirt should be cleaned off without delay, using lukewarm water and an interior cleaner, stain remover or appropriate cleaning fluid. Brush the fabric afterwards to restore its appearance.

If the vehicle will be stored for an extended period or if it is exposed to intense sunlight, cover all the seats or the windows to prevent fading.

 Use cleaning and car-care products that you can obtain at your BMW center. ◀

The buildup of an electrostatic charge on the seat covers, particularly if atmospheric humidity is low, can give the occupants an unpleasant electric shock if they touch metal body parts after leaving the vehicle. Although this not dangerous in any way, it can be avoided by touching a bare or polished metal part of the car while getting out.

Leather care

The leather upholstery* used by BMW is a natural product of the highest quality, processed using state-of-the-art methods to ensure that it will maintain its high quality for years to come, provided that it is properly cared for.

Because this product is manufactured using natural materials, you must make allowance for its special characteristics and for the peculiarities of its use and care.

Regular periodic cleaning and care are essential, as dust and road dirt act as abrasives in the pores and creases of the material. This leads to wear spots and premature brittleness on the surface of the leather. We therefore suggest that you clean the leather with a vacuum cleaner or cloth at frequent intervals.

For cleaning, use BMW leather cleaning foam.

Since dirt and grease gradually attack the protective layer of the leather, the cleaned surfaces should be treated with BMW leather care agent. This also acts as an antistatic agent.

For protection against dampness or moisture, treat the leather with a BMW impregnating agent.

We recommend that you perform this procedure twice a year on leather exposed to normal use.

Spills should be wiped up immediately. Remove grease and oil stains without rubbing, but rather by dabbing with spot remover.


If the upholstery will be exposed to intense sunlight, or if the vehicle is to be stored for an extended period, cover all leather surfaces to prevent fading (or better yet, cover the windows).



Use cleaning and car-care products that you can obtain at your BMW center. ◀




Cleaning agents can contain substances that are dangerous or that pose health risks. For this reason, always comply with the warnings and danger notices on the packaging. Open the doors or windows on your vehicle when cleaning the interior. Never clean your vehicle with solvents or other materials not specifically intended for this purpose. ◀



- 1 Front airbags for driver and passenger
- 2 Side impact Head Protection System (front)
- 3 Side airbags (front and rear*)

Important safety notices

 Don't remove the airbag restraint system's gas generator. Testing and servicing must be performed by trained technicians only. In the event of a malfunction, deactivation, or triggered actuation (as a response to an accident) of the airbag restraint system, consult your BMW center for repairs or service operations.

Do not modify or tamper with either the wiring or the individual components in the airbag system. These include the padded steering wheel hub, the instrument panel, the side trim panels of the front or rear doors and the roof pillars or the sides of the headliner. Do not apply adhesive materials to these components or cover or modify them in any way. Do not attempt to remove or dismantle the steering wheel.

To ensure compliance with official safety regulations, have an BMW center dispose of airbag generators.

Unprofessional attempts to service the system could lead to failure in an emergency or undesired airbag activation, either of which could result in personal injury. ◀

Consult your BMW center regarding special procedures if you intend to store the vehicle for more than three months.

138 Technical modifications to the vehicle

Any BMW center will be glad to inform you of the advisability, legal requirements and factory recommendations regarding technical modifications on your vehicle. For this purpose, the BMW center will require the Vehicle Identification Number and, in some cases, also the engine number.

Light-Emitting Diodes (LEDs)

Light-emitting diodes installed behind translucent lenses serve as the light source for many of the controls and displays in your vehicle. These LEDs resemble conventional lasers and are classified by law as "Class 1 light-emitting diodes."



Do not remove the protective lens and avoid staring directly at the unfiltered beam for extended periods (several hours). To do so could result in inflammation of the iris. ◀

OBD interface socket



The OBD interface socket for onboard diagnostics is located on the driver's side at the left-hand bottom of the instrument panel and under a cover. The cover has the letters "OBD" on it.

The purpose of the OBD system is to assure proper emission control system operation for the vehicle's lifetime by monitoring emission-related components and systems for deterioration and malfunction.

An illuminated indicator informs you of the need for service, not that you need to stop the vehicle. Your system should be checked, however, at the earliest possible opportunity.

If the indicator blinks or flashes, this indicates a high level of engine misfire. Reduce speed and contact your nearest BMW center immediately. Severe engine misfire over even a short period of time can seriously damage emission control components, especially the catalytic converter.

If the fuel filler cap is not on tight enough, the OBD system can detect leaking vapor and the indicator will light up. If the fuel filler cap is then tightened, the indicator will usually go out after a short period of time.



**Replacement procedures:**

- Onboard tool kit [142](#)
- Windshield wiper blades [142](#)
- Lamps and bulbs [142](#)
- Changing a wheel [149](#)
- Battery [152](#)
- Fuses [154](#)
- Microfilter [155](#)


In case of electrical malfunction:

- Fuel filler door [156](#)
- Sliding/Tilt sunroof [156](#)

Assistance, giving and receiving:

- Jump-starting [157](#)
- Towing the vehicle [158](#)

Overview**Controls and features****Operation, care and maintenance****Owner service procedures****Advanced technology****Technical data****Index**




The onboard tool kit is located in the luggage compartment lid.

Loosen the wingnut to open.

Windshield wiper blades




- 1 Rotate the wiper arm completely out from the windshield.
- 2 Position the wiper blade at an angle and pull the release spring (arrow).
- 3 Fold the wiper blade down and unhook it toward the windshield.
- 4 Pull the wiper blade past the wiper arm toward the top.
- 5 Insert a new wiper blade and apply pressure until you hear it engage.


 Use only wiper blades approved by BMW. ◀

Lamps and bulbs

The lamps and bulbs are essential factors contributing to the safety of your vehicle. For this reason, follow the instructions below carefully when replacing a bulb. If you are not familiar with any of the procedures, consult your BMW center.

 Do not touch the glass portion of a new bulb with your bare hands since even small amounts of impurities burn in to the surface and reduce the service life of the bulb. Use a clean cloth, paper napkin, or a similar material, or hold the bulb by its metallic base. ◀

A replacement bulb set is available from your BMW center.

 Whenever working on the electrical system, switch off the electrical accessory you are working on or disconnect the cable from the negative terminal of the battery. Failure to do this could result in short circuits.

To prevent injuries and damage, comply with any instructions provided by the bulb manufacturer. ◀

Lamps and bulbs




The illustration shows the left-hand side of the engine compartment.

1 Low beams


H7, 55 watt bulb

2 High beams

H7, 55 watt bulb

 The H7 bulb is pressurized. Therefore, wear safety glasses and protective gloves. Failure to comply with this precaution could lead to injury if the bulb is accidentally damaged during replacement. ◀


- 1 Turn the bulb holder to the left and remove it.
- 2 Remove and replace the bulb.

 When cleaning the headlamps, please observe the following:

- ▷ Do not clean by wiping with a dry cloth (this causes scratches). Never use abrasives or strong solvents to clean the covers.
- ▷ Remove dirt and contamination (such as insects) by soaking with BMW Car Shampoo and then rinsing with plenty of water.
- ▷ Always use a deicer spray to remove accumulated ice and snow – never use a scraper. ◀

Xenon lamps*

The service life of these bulbs is very long and the probability of a failure is very low, provided that they are not switched on and off an unusual number of times. If one of these bulbs should nevertheless fail, it is possible to continue driving with great caution using the front fog lamps, provided traffic laws in your area do not prohibit this.

 Because of the extremely high voltages involved, any work on the lighting system should be performed only by technicians with the appropriate qualifications. Failure to comply with this creates a risk of fatal injury. ◀



The illustration shows the left-hand side of the engine compartment.

Parking lamps

5 watt bulb

- 1 Turn the bulb holder to the left (arrow) and remove it.
- 2 Remove and replace the bulb.



Front turn signal indicator

21 watt bulb

- 1 Using a screwdriver, release the inner hook through the upper opening.
- 2 Pull the lamp toward the front.
- 3 Applying light pressure, turn the bulb to the left. Remove and exchange the bulb.



- 4 Insert the 2 pins on the lamp into the guides on the vehicle.
- 5 Guide the lamp into position. Apply gentle pressure until you hear it engage.



Side turn signal indicator*


5 watt bulb

- 1 Use finger pressure against the rear end of the lens (arrow) to press it forward for removal.
- 2 Apply gentle pressure to the bulb while turning it to the left to remove.




Front fog lamps

HB4, 55 watt bulb

 The bulb is pressurized. Therefore, wear safety glasses and protective gloves. Failure to comply with this precaution could lead to injury if the bulb is accidentally damaged during replacement. ◀


- 1 Using a screwdriver, carefully loosen the lamp.
- 2 Applying light pressure, turn the bulb to the left. Remove and exchange the bulb.



Tail lamps

Tail lamps (4): bulbs 21/4 watts
 Remaining bulbs: 21 watts

- | | |
|--------------------------|--------|
| 1 Turn signal indicator | yellow |
| 2 Backup lamps | white |
| 3 Tail lamp | red |
| 4 Tail lamps/Brake lamps | red |



The illustration shows the right-hand luggage compartment opening.

Bulbs in the fender:

All of the bulbs are integrated in a central bulb holder.

- 1 Release the bulb holder (arrow, partial view) and remove.
- 2 Unplug the power supply receptacle. Set the bulb holder aside (on the luggage compartment floor, for example).
- 3 Applying light pressure, turn the bulb to the left. Remove and exchange the bulb.
- 4 Plug in the power supply receptacle.
- 5 Position the bulb holder for reinstallation. Apply gentle pressure on the button (arrow, partial view) until you hear it engage.



Bulbs in the luggage compartment lid:

- 1 Using a screwdriver, loosen the two clips.




- 2 Fold the trim panel down (arrow 1). Disengage the bulb holder (arrow 2) and remove it.
- 3 Applying light pressure, turn the bulb to the left. Remove and exchange the bulb.
- 4 Press the bulb holder into position until you hear it engage.
- 5 Reinstall the trim with the two clips.



Center (high-mount) brake lamp

LED light bar on the rear window.

Please contact a BMW center in the event of a malfunction.



License plate lamps

5 watt bulb

- 1 Place a screwdriver in the slot and press toward the left (arrow) to release the lens.
- 2 Replace the bulb.



Interior lamps

Front

The illustration provides an example of the interior lamps when equipped with reading lamps*.

Interior lamps (2 x 5 watt bulbs)

- 1 Using a screwdriver, press the lamp out toward the front.
- 2 Remove the lens and pull the bulb out of the contact studs.

Interior lamps (6 watt bulb) with reading lamps* (2 x 6 watt bulbs)

- 1 Using a screwdriver, press the lamp out toward the front.
- 2 Turn the bulb holder to the left and remove.
- 3 Remove and replace the bulb.



Rear


The illustration provides an example of the interior lamps when equipped with reading lamps*.

Interior lamps (5 watt bulb)

- 1 Using a screwdriver, press the lamp out toward the front.
- 2 Turn the bulb holder to the left and remove.
- 3 Remove and replace the bulb.

Interior lamps (6 watt bulb) with reading lamp* (6 watt bulb)

- 1 Press the lamp out using a screwdriver.
- 2 Turn the bulb holder to the left and remove.
- 3 Remove and replace the bulb.



Lighted vanity mirror*

10 watt bulb

- 1 Remove the bulb housing – use a screwdriver if necessary.
- 2 Replace the bulb.

Footwell lamps*

5 watt bulb

- 1 Press the lamp out using a screwdriver.
- 2 Replace the bulb.

Glove compartment lamp

5 watt bulb

- 1 Press the lamp out using a screwdriver.
- 2 Replace the bulb.

Luggage compartment lamps

One lamp each in the bulb holder of the tail lamp assembly: 10 watt bulb.

- 1 Apply a screwdriver to the recess and remove the lens.
- 2 Replace the bulb.

Changing a wheel


⚠ Take these precautionary measures if you have either a flat tire or are changing the tire. Stop the vehicle as far as possible from passing traffic. Park on a firm, flat surface. Switch on the hazard flashers. Turn the steering wheel to the straight-ahead position, remove the key and engage the steering lock. Shift into 1st or reverse (selector lever in "Park" with automatic) and engage the parking brake. Have all passengers leave the car and remain well away from your immediate working area (behind a guardrail, for instance). If a warning triangle or portable hazard warning lamp is available, set it up on the roadside at an appropriate distance from the rear of the vehicle. Comply with all applicable safety guidelines and regulations. Change the wheel only on a level, firm surface that is not slippery. Avoid jacking the car on a soft or slippery support surface (snow, ice, loose gravel, etc.), as it could slide sideways. Position the jack on a firm support surface. Do not place wooden blocks or similar objects under the jack. If you do so, the jack might not be able to reach its full

support capacity because of the limited height.

Do not lie under the vehicle or start the engine when the vehicle is supported by the jack. Failure to comply with this creates a risk of fatal injury. ◀

Your BMW has either a spare wheel* or a space-saver spare tire* for temporary use and to ensure your mobility.

▶ To remove the spare wheel*, lift the floor panel in the luggage compartment completely out (refer to page 41). ◀





You will need the following:

In order to avoid rattling noises later, note the position of the tools when you remove them and return them to their original position when you are through using them.

- ▶ Jack (1)
 - Raise the floor panel in the luggage compartment (refer to page 41) and loosen the red wing nut (arrow). When you have completed work, screw the jack all the way back down. Fold the handle back and insert it in its holder.
- ▶ Wedge (2)
 - The wedge, or wheel chock, is located behind the jack on the luggage compartment's rear wall. Loosen the wing nut to remove it.

150 Changing a wheel



- ▷ Spare tire* or space-saver spare tire*
Located next to the jack.
Loosen the wing nut (arrow) by hand, remove the storage tray and take out the spare wheel.
- ▷ Lug wrench – is in the onboard tool kit on the underside of the luggage compartment lid (refer to page 142).

Procedure


- 1 Read and comply with the safety precautions provided on the previous page.
- 2 Secure the vehicle from rolling:
Place the wedge against the rear surface of the front tire on the side opposite the side being raised. If the vehicle is parked on a downward slope, place the wedge securely in front of the tire. If the wheel must be changed on a surface with a more severe slope, take additional precautions to secure the vehicle from rolling.
- 3 If your wheels are equipped with full wheel covers*: Reach into the ventilation openings and pull the cover off.
- 4 Loosen the lug bolts 1/2 turn.
- 5 Position the jack at the jacking point closest to the flat tire (refer to the center illustration) so that the jack base is vertically below the jacking point and the entire surface of the head of the jack will move into the square recess of the jacking point (refer to the illustration detail) when the jack is cranked.
- 6 Jack the car up until the wheel you are changing is raised from the ground.
- 7 Unscrew the lug bolts and remove the wheel.
- 8 Remove accumulations of mud or dirt from the mounting surfaces of the wheel and hub; clean the lug bolts.




- 9 Position the new wheel or the space-saver spare tire* on the hub and screw at least two lug bolts finger-tight into opposite bolt holes.
- 10 Screw in the remaining lug bolts. Tighten all the bolts securely.
- 11 Lower the jack and remove it from beneath the car.
- 12 Tighten the lug bolts in a diagonal pattern.



- 13 Wheels with full wheel covers: Position the wheel cover with the valve opening over the valve (arrow) and press it onto the wheel with both hands.
- 14 Check and correct the tire's inflation pressure at the earliest possibility. For vehicles with RDC (Tire Pressure Control)*: Reactivate the system after mounting either the spare tire or after inflating tire(s) to proper pressure. Refer to page 80.

 Use only the full wheel cover installed by the factory. Other wheel covers may not fit securely. The full wheel cover may not be installed on the space-saver spare tire* since this could damage the cover. ◀

 The vehicle jack is designed for changing wheels only. Do not attempt to raise another vehicle model with it or to raise any load of any kind. To do so could cause accidents and personal injury. Have the lug bolts checked for proper tightness with a calibrated torque wrench at the earliest possibility [torque specification: 72 lb.ft. (100 Nm)]. ◀

When storing the wheel, be sure that you do not damage the retaining pin in the spare tire recess.

If light-alloy wheels other than Original BMW light-alloy wheels have been mounted, it may be necessary to use different lug bolts for those wheels.


Replace the defective tire as quickly as possible and have the new wheel balanced.

Driving with the space-saver spare tire*

Drive cautiously and do not exceed a speed of 45 mph (80 km/h).

Be aware that vehicle handling will be altered. Slower brake response time, longer braking distances and changed steering characteristics may be anticipated when approaching limit conditions.

The changes in handling characteristics will be even more pronounced in conjunction with winter tires.

 Only one space-saver spare tire may be mounted at one time. Mount a wheel and tire with the same size and specifications as the others at the earliest possible opportunity. Maintain correct tire pressures. Refer to page 28. ◀


Battery**Battery location**

The battery is located at the right-rear of the luggage compartment. Raise the luggage compartment floor panel (refer to page 41). Use a screwdriver or a coin to loosen the two fasteners in the illustration 1/4-turn. Loosen the third fastener in the upper-center side trim panel. Remove the fasteners. In order to remove the storage tray, slide the side trim panel slightly upward.

**Charge condition**

The "Magic Eye*" is a hydrometer that allows you to read the charge condition of the battery:


- ▷ Green: adequate charge.
- ▷ Black: not adequately charged. The battery must be recharged. Please contact your BMW center for additional information.
- ▷ Yellow: Replace the battery.

 The service life specified for the battery can be achieved only if it is always kept adequately charged. If the vehicle is primarily used for stop-and-go traffic, be sure to check the charge state often. ◀

Battery

Battery care

The battery is absolutely maintenance-free, that is, the original electrolyte will normally last for the service life of the battery under moderate climatic conditions.

 For all questions that regard the battery, please consult your BMW center. Since the battery is maintenance-free, the following is for your information only. ◀

Symbols

You will find the following symbols on your car battery. To avoid injury, please comply with the corresponding precautions whenever you work with or near the battery.



Before handling the battery, please read the following information.



Wear eye protection. Do not allow particles containing battery acid or lead to come into contact with your eyes, your skin, or your clothing.



Battery acid is extremely corrosive. Wear eye protection and protective gloves. Do not tip the battery. Battery acid can leak from the ventilation openings.



Do not allow children access to batteries and battery acid.



Never allow sparks or open flame in the vicinity of the battery. Avoid sparks from electrical cables or electrical equipment. Turn the key to position 0 in the steering lock when disconnecting or connecting the battery. Do not short-circuit the battery terminals. This creates a risk of injury from high-energy sparks.



A highly-explosive gas is generated when the battery is charged.



If battery acid is splashed into your eyes, rinse them thoroughly with clear water for at least 15 minutes. Consult a physician immediately. If your skin or clothing are splashed by acid, rinse immediately with ample clear water. If electrolyte is accidentally swallowed, consult a physician immediately.



In order to protect the battery case from ultraviolet radiation, do not place it in direct sunlight. A discharged battery can freeze. Store the battery in areas where temperature remains above freezing.

Removal and installation



Do not disconnect the battery when the engine is running. If you do so, the ensuing voltage surge will damage the vehicle's onboard electronics.

Do not make any modifications in the wires to the positive terminal. If you do so, the protective function of the safety battery terminal is no longer ensured. Repair and disposal must be performed by trained technicians only. ◀

When removing the battery, disconnect the cable on the negative terminal first, then the cable on the positive terminal. Loosen the center adjusting screw on the battery retaining strap (use the screwdriver included with the onboard tool kit) and disconnect the strap.


When installing a battery, connect the positive terminal first, then connect the negative terminal.



When installing a battery, be sure that it is mounted properly and that the retaining bracket is installed with the center adjustment screw. If this is not done, the battery will not be adequately secured in case of an accident. ◀


Charging the battery


Charge the battery in the vehicle only when the engine is not running.

 Before doing any work on the electrical system, be sure to unclamp the cable from the battery's negative terminal. Failure to do so can result in short-circuits, a fire or personal injury. ◀


If the vehicle is to be parked longer than four weeks, disconnect the battery from the vehicle's electrical system by disconnecting the negative terminal cable and then recharge using a suitable charging device.

If you intend to store your car for longer than twelve weeks: Remove the battery, charge it and store it in a cool (but frost- and dust-free) room. Every three months and before reinstalling the battery, have it recharged. If it is not recharged, it will not be serviceable. Every time the battery is discharged, especially over extended periods, its service life is reduced.

 Return used batteries to a recycling center or your BMW center. Maintain the battery in an upright position for transport and storage. Secure the battery to prevent it from tilting during transport. ◀

 Storage periods during which the battery is disconnected are not taken into consideration by the Service Interval Display for changing the brake fluid.

For this reason, be sure that the brake fluid is changed every two years, regardless of the information displayed. Read and comply with the information on page 129 covering this subject. ◀

Fuses

If an electrical accessory should fail, switch it off and check the fuse.


In the glove compartment

- 1 Open the glove compartment and turn the two white quick-release fasteners outward. Spare fuses and plastic tweezers are located on the fuse holder.
- 2 Use the plastic tweezers to remove the fuse for the accessory or equipment that has stopped working.
- 3 If the fuse is burned through (the metal strip is melted and separated), replace it with a new fuse of the same ampere rating (color code).

Fuses


The fuses, their respective ampere ratings and the equipment in their circuits are all indicated below the fuse holder.

To close the fuse holder, snap it into position at the top and turn the two fasteners inward.


 Do not attempt to repair a burned fuse or replace it with a fuse having a different color or amperage rating. To do this could cause a fire in the vehicle resulting from a circuit overload. ◀

If a fuse blows repeatedly, refer the problem to your BMW center for repair.

Microfilter




- 1 Open the hood.
- 2 Loosen the three fasteners (arrow) with a 1/4-turn.
- 3 Remove the filter cover.



- 4 Remove the filter by pulling it forward. Install the new filter.
- 5 Position the filter cover and secure it with the three fasteners.

**Manual release**

Pull the knob with the fuel pump symbol (arrow) on the right trim panel of the luggage compartment.


**Manual operation**

- 1 Remove the interior lamp (refer to page [147](#)), reach into the opening and push the panel out.
- 2 Turn the sunroof's steel crank with the Allen wrench from the onboard tool kit (refer to page [142](#)) in the desired direction.

Jump-starting

Do not use spray starter fluids.

If the battery is discharged, the engine can be started with the use of two jumper cables and the battery of another vehicle. Use only jumper cables with fully insulated grips on the terminal clamps.

 Do not touch the parts conducting electrical current while the engine is running. Failure to comply with this creates a risk of fatal injury. ◀


Carefully comply with the following instructions to avoid personal injury or damage to one or both vehicles:

- 1 Be sure that the battery on the support vehicle is also rated at 12 volts, and that the capacities of the two batteries (Ah) are roughly comparable (printed on casing).
- 2 Leave the discharged battery connected to the vehicle's electrical system.
- 3 Make sure that there is no contact between the bodywork of the two vehicles – this creates a risk of short circuits.
- 4 Start by connecting the jumper cable from the positive terminal of the support vehicle to the positive terminal connector located in your BMW's en-




gine compartment. The cover of the positive terminal connector is marked with a "+" sign. Refer to the illustration. Remove by pulling the tab (arrow 1).

- 5 Then connect the negative terminals. Attach the cable to either the support vehicle's negative battery terminal (-), or to a suitable ground on its engine or bodywork. Then connect the other end of the cable to a ground on the engine or on the bodywork of the vehicle that is to be started. There is a special nut provided for this on the BMW (arrow 2).

 Follow the same sequence for connecting the jumper cables when helping other vehicles. If you do not, there is the risk of injury if sparks are generated at the battery. ◀

- 6 Start the engine of the support vehicle and let it run.
- 7 Start the engine on the vehicle needing the jump-start, and allow it to run as usual. If the first start attempt is not successful, wait a few minutes before another attempt in order to allow the discharged battery to recharge.
- 8 Before disconnecting the jumper cables from your BMW, turn on the rear window defroster and set the blower to the highest speed; allow the engine to run approx. 10 seconds. This will prevent a voltage surge from the voltage regulator to the electrical accessories.
- 9 Then disconnect the jumper cables in reverse sequence.

Depending on the cause of the fault, recharge the battery.



Tow fitting

The screw-in tow fitting is stored in the onboard tool kit; be sure that it remains in the vehicle at all times. This fitting is designed for installation in the tow sockets located at the front and rear of the vehicle. It is intended for towing on paved road surfaces only. This fitting should not be used to pull a vehicle out of deep snow, mud, sand, etc. Always comply with all applicable towing laws and regulations.

Access to tow sockets

Front

Use a screwdriver in the upper section of the recess to press the cover out.

Rear

Use a screwdriver in the upper section of the recess to press the cover out.



Screw the tow fittings in completely and tightly. If you do not, the threads could be damaged. Do not tow the vehicle by any components of the running gear, or lash them down in any way. If you do so, the components could be damaged, leading to possible accidents. ◀


Towing with a commercial tow truck

- ▷ Do not tow with sling-type equipment.
- ▷ Use a wheel lift or flat bed carrier.
- ▷ Please comply with applicable towing laws.



Never allow passengers to ride in a towed vehicle for any reason. Never attach tie-down hooks, chains, straps, or tow hooks to the tie rods, control arms, or any other part of the vehicle suspension. If you do so, severe damage will occur to these components. ◀





Adaptive Transmission Control (ATC) [162](#)
Airbags [163](#)
Dynamic Stability Control (DSC) [163](#)
Radio reception [164](#)
Safety belt tensioner [164](#)
Interior rearview mirror with automatic dimming feature [165](#)
Rain sensor [166](#)
Tire Pressure Control (RDC) [167](#)
Self-diagnostics [168](#)
Xenon lamps [169](#)

Overview

Controls and features

Operation, care and maintenance

Owner service procedures

Advanced technology

Technical data

Index



On vehicles with an automatic transmission, the ATC (Adaptive Transmission Control) uses a number of factors to calculate the gear which provides the maximum efficiency. In this process, it considers your individual driving style as well as current driving conditions.

ATC recognizes your personal driving style from the positions and movements of the accelerator pedal, deceleration when braking, and lateral acceleration through curves. Based on different shift characteristics – from comfort-oriented to performance-oriented – ATC will select the appropriate gear.

In order to include driving conditions in its calculations, ATC registers curves and both uphill and downhill gradients. For example, if you maintain speed through a curve, the transmission does not shift up. On uphill gradients, it shifts up only when the engine speed increases in order to make more efficient use of power reserves. On downhill gradients, ATC shifts down when the speed of the vehicle increases and the driver must apply the brakes.



Deceleration sensors continuously monitor the acceleration forces acting upon the vehicle. If, as the result of a frontal collision, a deceleration is reached at which the protection of the safety belts alone is no longer adequate, the gas generators of the driver and passenger-front airbags are ignited. However, the passenger-side airbag is only triggered if an additional sensor has recognized that the passenger seat is occupied.

In the event of a side collision, the Head Protection and side airbags in the front or rear* are triggered if necessary.

The airbags located under the marked covers inflate and unfold in a matter of a few milliseconds. In this process, they tear through the designed separation points of the upholstered covers or press them out.

Because the inflation process must be virtually instantaneous, it is necessarily accompanied by a certain amount of ignition and inflation noise. The gas required to inflate the airbags is not dangerous, and the smoke associated with it dissipates.

The entire process is completed within fractions of a second.


Highly sensitive sensors monitor the number of revolutions of the wheels. When equipped with DSC, they also monitor steering angle, lateral acceleration, brake pressure and the movement of the vehicle around its vertical axis.

If differences in the wheel speeds occur, the system counteracts the danger of wheelspin by reducing engine torque. If necessary, the system also responds with additional application of the brakes at the rear wheels.

If the system detects an instability in the vehicle's condition, the braking action can also be directed to the front wheels by the DSC in order to help stabilize the vehicle.

You may need some time to become accustomed to this system's intervention. However, it provides optimum drive force and driving stability.

The braking intervention may be accompanied by sounds specific to the system.



AM radio provides reception across a considerable distance because the broadcast signals not only travel along the ground as surface waves, but they are also reflected from the ionosphere as atmospheric waves.

Frequency-modulation (FM) provides substantially better sound quality than AM. However, because FM transmissions rely on line-of-sight broadcast waves, their effective reception range is limited.

The limitations inherent to radio reception in a moving vehicle have been minimized by a number of innovative system designs:

The "Radio Data System" (RDS) makes sure that, for broadcast stations sending on several frequencies, the radio automatically tunes to the frequency with the best reception quality.

The Diversity Antenna system employs several FM antennas integrated within the rear window to provide three separate sources for receiving broadcast waves. An integral processor automatically selects the antenna with the best FM reception quality at any given time. The selection of the antenna takes place within milliseconds, and is therefore not noticed by the radio listener.




The safety belt tensioner responds to severe collisions by tightening the belts to ensure that occupants remain firmly positioned in their seats. A gas-pressure system retracts the buckle assembly to tension the shoulder and lap belts within fractions of a second. This reduces the tendency to slide under the lap belt.



The semisolid reacts chemically to this electrical current, thus providing dimming of the mirror through an infinitely-variable range (electrochromic technology).

As a result, it is no longer necessary to dim the mirror manually, and the driver can concentrate completely on traffic conditions.

The interior rearview mirror with automatic dimming feature reduces blinding from following traffic by adapting the intensity of the reflected images to correspond to levels of light registered by the unit's sensors. The mirror reverts to its undimmed setting as soon as the light source disappears. One lamp sensor is mounted on the front of the mirror housing. This sensor, which is directed forward, measures light intensity in the area ahead of the vehicle. The second sensor is integrated within the mirror's glass. The electronic control system compares the light intensity from front and rear. The difference provides the basic parameter used to modulate an electrical current and induce chemical changes in a semisolid layer incorporated in the lens.



When the system is set to the "Intermittent" wiper speed, the wipers react immediately – if water is splashed onto the windshield by vehicles traveling ahead of you, for example. As a result, the rain sensor provides a contribution to driving safety and comfort.

Depending on the degree of wetness on the windshield, the rain sensor controls the operation of the windshield wipers.

Infrared light is carried along the surface of the windshield in an optical conductor in such a manner that it is reflected completely when the windshield is dry. The quantity of reflected light is measured.

If there is moisture on the glass, the amount of light reflected is reduced since the infrared light at the surface of the windshield can escape. The quantity of reflected light is thus a means of gauging the degree of wetness on the windshield.



Near every wheel is an antenna in the body that receives the signal from the wheel. A central electronics system evaluates the quadruple signals and forwards any changes. The RDC provides an important contribution to driving safety.

This system regularly checks tire pressure and monitors all four tires even while driving, so you don't have to.

Behind the valve stem in every wheel, there is an electronic chip that is designed for severe-duty applications and long service life. It contains a pressure sensor, a transmitter and a battery. The pressure is measured in extremely short time intervals and then transmitted by a radio signal. If an irregularity is detected, the transmission rate is increased.



All of the important electrical and electronic systems in the vehicle are tested regularly and automatically – the driver does not have to perform any extra operations or adjustments.

The indicator lamps also come on briefly after the ignition has been turned on.

While you are driving, the functional status of the actuator motors (for the windshield wipers, power windows, seats, sunroof, etc.) is constantly analyzed by current measurements in their relays.

In the same manner, the electrical resistance of the airbag ignition generators and all of the remaining airbag components is measured at all times. Any fault in this system would be detected immediately by a current fluctuation that would necessarily accompany it. The fault would be indicated immediately by the airbag warning lamp.


Even after you shut off the engine, the overall functional status of your vehicle is monitored. For example, all of the flaps of the heating and ventilation system travel to the nearest limit position. This action ensures that the system will be able to provide defrosting, regardless of other circumstances (if a malfunction in the heating or ventilation system should occur during the night while the vehicle is parked, for instance).

A calibration cycle runs every tenth time the engine is shut off. During this cycle, the actuator motors of all the heating and ventilation flaps travel to their limit stops in both directions. The limit positions and the return travel paths are checked in this manner in order to ensure that appropriate adjustments for the operating elements can be made at any time.

You will hear the sounds of the air flaps as the heater/ventilation system carries out its self-diagnostic functions after the ignition is shut off. All of the other self-diagnostics functions operate silently in the background.

Any faults detected during these self-diagnostics can be read out by your BMW center during the next regularly-scheduled maintenance and corrected with a minimum of time.

Xenon lamps*




The xenon lamp provides forward illumination with significantly more brightness and uniformity than the traditional halogen lamp.

In a xenon lamp, an electric arc replaces the filament in order to generate intense illumination. A gas mixture in a quartz glass tube with metal vapor is ignited by a high electric voltage. The arc that is generated is then sustained by a lower voltage. When the lamp is turned on, there is a brief warm-up period. Maximum brightness is attained in approx. 15 seconds.

Xenon lamps provide significantly-improved visibility, especially during adverse weather conditions and driving situations, (driving at night in heavy rain or through road repair areas where there are no lane markers, for instance).

Xenon lamps make a significant contribution to highway safety since other highway users, bicyclists and motorcyclists in the right lane, and pedestrians are more easily detected.



Engine data 172
Dimensions 173
Weights 174
Capacities 175
Electrical system 176
Ribbed V-belt 176



Overview

Controls and features

Operation, care
and maintenance

Owner service procedures

Advanced technology

Technical data

Index

Overview

Controls

Car care

Repairs


Technology

Data

Index

172 Engine data

| | | BMW 323i | BMW 328i |
|-----------------------------------|---------------------------|---|--------------------|
| Displacement | cu.in. (cm ³) | 152.2 (2,494) | 170.4 (2,793) |
| Number of cylinders | | 6 | 6 |
| Max. output at engine speed | hp (kW) RPM | 170 (127) 5,500 | 193 (144) 5,500 |
| Maximum torque at engine speed | lb.ft (Nm) rpm | 181 (245) 3,500 | 206 (280) 3,500 |
| Compression ratio | | 10.5 | 10.2 |
| Stroke | in. (mm) | 2.95 (75) | 3.31 (84) |
| Bore | in. (mm) | 3.31 (84) | 3.31 (84) |
| Fuel-injection system | | Digital-electronic engine-management system | |



Dimensions in () apply to 328i.
 Minimum turning circle dia. 34.4 feet (10.5 m).

460us295

174 **Weights**

| | | BMW 323i | BMW 328i |
|---|------------------|---------------|---------------|
| Curb weight (with one person, ready for operation, full tank of fuel, options not included) | | | |
| with manual transmission | lbs (kg) | 3,153 (1,430) | 3,197 (1,450) |
| with automatic transmission | lbs (kg) | 3,213 (1,457) | 3,256 (1,477) |
| Approved gross vehicle weight | | | |
| with manual transmission | lbs (kg) | 4,211 (1,910) | 4,270 (1,937) |
| with automatic transmission | lbs (kg) | 4,255 (1,930) | 4,314 (1,957) |
| Approved front axle weight | lbs (kg) | 1,962 (890) | 1,973 (895) |
| Approved rear axle weight | lbs (kg) | 2,348 (1,065) | 2,370 (1,075) |
| Approved roof load capacity | lbs (kg) | 165 (75) | 165 (75) |
| Luggage compartment capacity | cu. ft. (liters) | 14.5 (410) | 14.5 (410) |

Never exceed either the approved axle weights or the gross vehicle weight.

| | | | Notes |
|--|--------------------------------|--|---|
| Fuel tank reserve | gal. (liters) gal. (liters) | approx. 16.6 (approx. 63) approx. 2.1 (approx. 8) | Fuel specification: Page 26 |
| Windshield washer system/ Headlamp washer system* | quarts (liters) | approx. 5.6 (approx. 5.3) | For details: Page 124 |
| Cooling system including heater circuit | quarts (liters) | approx. 8.9 (approx. 8.4) | For details: Page 128 |
| Engine oil and filter change | quarts (liters) | approx. 6.9 (approx. 6.5) | BMW High Performance Synthetic Oil For details: Page 126 |
| Manual transmission, automatic transmission and differential | | - | Lifetime fluid, no fluid change required. |

176 Electrical system

Battery

12 V, 80 Ah

Spark plugs

NGK BKR 6 EQUIP

Bosch FGR 7 DQP (not released at this time)

Ribbed V-belt

Water pump – AC alternator – Power steering

Ribbed V-belt 6 PK x 1538

A/C compressor


Ribbed V-belt 5 PK x 863



You can obtain Original BMW Parts and Accessories, as well as professional advice from your BMW center. ◀

A B C

P Q R



Everything from A to Z 180
Owner service procedures 186

Overview

Controls and features

Operation, care
and maintenance

Owner service procedures

Advanced technology

Technical data

Index

Overview

Controls

Car care

Repairs

Technology

Data

Index

Everything from A to Z

A

ABS (Antilock Brake System) [22](#), [106](#)
Accessories [6](#)
Activated-charcoal filter [90](#), [155](#)
Adaptive Transmission Control (ATC) [65](#), [162](#)
Adding engine oil [125](#)
Adding washer fluid [124](#), [175](#)
Adjusting the backrest [47](#)
Adjusting the steering wheel [51](#)
Adjusting the thigh support area [49](#)
Air distribution [88](#)
Air nozzles [86](#)
Air outlets [86](#)
 ventilation [86](#)
Air pressure [113](#)
Air supply [89](#)
Airbags [21](#), [56](#), [137](#), [163](#)
Alarm system [42](#)
Antenna [112](#)
Antenna, Diversity [164](#)
Antifreeze [128](#)
 radiator [110](#)
Antilock Brake System (ABS) [22](#), [106](#)
Anti-theft alarm system [42](#)
Aquaplaning [104](#), [113](#)
Armrest [93](#)

Ashtray [95](#)
 front [95](#)
 rear [96](#)
ATC (Adaptive Transmission Control) [65](#), [162](#)
AUC (Automatic recirculated-air control) [89](#)
Automatic car washes [132](#)
Automatic climate control [86](#)
 removing condensation from the windows [89](#)
Automatic cruise control [71](#)
Automatic dimming, interior rearview mirror [53](#)
Automatic recirculated-air control (AUC) [89](#)
Automatic transmission with Steptronic [22](#), [65](#)
Automatic windshield washer [69](#)
Average consumption [77](#)
Average speed [77](#)
Axle loads [174](#)

B

Backup lamps [64](#)
 bulb replacement [145](#)
Battery [152](#), [176](#)
 capacity [176](#)
 charge [154](#)

 discharged [157](#)
 removal and installation [153](#)
Battery charge current [20](#)
Battery Safety Terminal (BST) [153](#)
Belts [54](#)
Blower [89](#)
BMW High Performance Synthetic Oils [126](#)
BMW Sports Seat [49](#)
Bore [172](#)
Brake fluid [129](#)
Brake hydraulic system [20](#)
Brake lamps
 bulb replacement [145](#)
Brake pads [22](#)
Brakes [108](#)
 malfunctions [109](#)
Break-in procedure [104](#)
Breaking in the vehicle [104](#)
BST (Battery Safety Terminal) [153](#)
Bulb replacement [142](#)

C

Capacities [175](#)
Car Memory [53](#)
Car radio [112](#)
 refer also to the separate Owner's Manual

Car radio
 reception [112](#), [164](#)
Car vacuum cleaner, connecting [96](#)
Car wash [132](#)
Care
 exterior [133](#)
 interior [134](#)
Care of upholstery [135](#)
Care of wool velour [135](#)
Cargo loading [99](#)
Caring for the vehicle finish [133](#)
Catalytic converter [105](#)
CBC (Cornering Brake Control) [21](#), [107](#)
Cellular phone [95](#), [112](#)
 refer also to the separate Owner's Manual
Center (high-mount) brake lamp [147](#)
Center armrest [93](#)
Central locking system [34](#)
 button [38](#)
Changing a tire [149](#)
Changing a wheel [149](#)
Charge indicator lamp [20](#)
Check Control [75](#)
Child restraint systems [55](#), [59](#)
Child seat [59](#)
Child-safety locks [56](#)
Cigarette lighter [96](#)

Everything from A to Z

- Clock 75
 - refer also to the Radio or Onboard Computer Owner's Manual
- Cockpit 16
- Coin holder, cup holder 93
- Combination switch 68
- Compression 172
- Computer 76
- Configure settings 53
- Consumption 77
- Consumption display 74
- Coolant 110, 128, 175
 - antifreeze 110
- Coolant temperature gauge 74
- Cooling system 175
- Cornering Brake Control (CBC) 21, 107
- Cruise control 71
- Cruising range 77
- Curb weight 174

- D**
- Dash lighting 82
- Dashboard 16
- Data
 - dimensions 173
 - engine 172
 - weights 174
- Daytime-driving lamp switch 82
- Defrost position 89
- Defroster, rear window 90
- Defrosting the windows 89
- Digital clock 75
- Dimensions 173
- Dipstick 125
- Disc brakes 108
- Displacement 172
- Display lighting 82
- Displays 18
- Distance warning 78
- Diversity Antenna 164
- Divided rear backrest 97
- Door key 32
- Door locks, care 110
- Doors
 - child-safety locks 56
 - emergency operation 34
 - unlocking and locking 34
- Draft-free ventilation 90
- Driving hints 104
- Driving in winter 110
- Driving lamps 82
- Dynamic Stability Control (DSC) 22, 79, 163

- E**
- Electric power windows 44
- Electrical accessories, failure 154
- Electrical system 176
- Electronic vehicle immobilizer 33
- Elements of operation 16
- Emergency operation, doors 34
- Energy Control 73
- Engine
 - starting 61
- Engine compartment 122
- Engine coolant 128, 175
- Engine data 172
- Engine oil
 - capacity 175
 - consumption 125
 - pressure 20
 - quality 126
 - specifications 126
 - viscosity 126
- Engine oil level 21, 22
 - check 125
- Engine speed 172
- Exterior mirrors 52

- F**
- Failure messages 75
- Fault
 - ABS 107
- Fault displays 75
- Filler cap cover 26
- Filling capacities 175
- Filling the washer reservoir 175
- First aid 25
- First-aid kit 25
- Fittings, towing and tow-starting 158
- Flashlight 92
- Flat tire 113, 149
- Fog lamps 83
- Folding rear backrest 97
- Footbrake 108
- Footwell lamps 83
 - bulb replacement 148
- Front fog lamps 83
 - bulb replacement 145
- Front seat-adjustment 47
- Frost protection, radiator 128
- Fuel 26
 - fuel injection 172
- Fuel consumption 77
- Fuel consumption display 74
- Fuel filler door
 - releasing following an electrical malfunction 156
- Fuel gauge 74
- Fuel quality 26
- Fuel reserve indicator lamp 74
- Fuel tank capacity 175
- Fuel tank gauge 74
- Functional status 168
- Fuses 154

- G**
- Gasoline 26
- Gasoline gauge 74
- Glove compartment 92

Everything from A to Z

Glove compartment lamp
bulb replacement 148
Gross vehicle weight 174

H

Handbrake 63
Handsfree system 95
Hazard warning flashers 25
Hazard warning triangle 25
Head restraint 48
Headlamp covers,
care 132, 143
Headlamp flasher 83
Headlamp washer
system 124, 175
Headlamp washers 70
Heated seats 91
Heavy loads 99
Height 173
HiFi system – harman
kardon 92
High beams 23, 68, 83
bulb replacement 143
Hood release 120
Horn 17
Hubcap 150

I

Ice warning 76
Icy roads 76
Identification, tires 116

Ignition key 32
Ignition lock 61
Indicator lamps 20
Inflated pressure 27, 113
Inflation pressure
monitoring 80, 167
INSPECTION 74
Installing a child restraint
system 60
Instrument cluster 18
Instrument lighting 82
Instrument panel 18
Interaxle tire rotation 115
Interface socket 96
for Onboard
Diagnostics 139
Interference
cellular phones 112
Interior lamps 36, 83
bulb replacement 147
remote control 36
Interior motion sensor 42
Interior rearview mirror 52
automatic dimming
feature 53, 165
Interlock 61
Intermittent wipe 68

J

Jack 149
Jump-starting 157

K

Key Memory 53
Keys 32
with remote control 32

L

LAMPS ON warning 82
Lashing eyes 99
Leather care 136
Length 173
License plate lamp
bulb replacement 147
Light switch 82
Light-alloy wheels 118
Lighter 96
Load-securing devices 99
Louvers 86
Low beam headlamps 82
Low beams
bulb replacement 143
Lug bolts 150
Lug wrench 149
Luggage compartment 41
capacity 174
floor mat 41
floor panel 41
remote control 37
Luggage compartment
lamps
bulb replacement 148

Luggage compartment
lid 39
emergency release 39
securing separately 39
Luggage compartment
lighting 39
Luggage rack 100
Lumbar support 49

M

M+S tires 117
Maintenance 74, 131
Malfunction displays 75
Manual transmission 64
Manually controlled
recirculated-air 89
Memory 50
MFL (Multifunction steering
wheel) 24
Microfilter 90, 155
Mirror memory 50
Mirrors 52
Mobile phones 112
Modifications,
technical 6, 138
Multifunction steering wheel
(MFL) 24

N

Neckrest 48

- O**
- OBD interface socket [139](#)
 - Obstruction protection [44](#)
 - Odometer [73](#)
 - Oil
 - capacity [175](#)
 - consumption [125](#)
 - dipstick [125](#)
 - quality [126](#)
 - specifications [126](#)
 - viscosity [126](#)
 - Oil additives [125](#)
 - Oil change intervals, see the
 - Service and Warranty Information Booklet
 - Oil filter change [175](#)
 - Oil level
 - check [125](#)
 - indicator lamp [20](#)
 - Oil pressure, indicator lamp [20](#)
 - OILSERVICE [74](#)
 - Onboard computer [76](#)
 - Onboard tool kit [142](#)
 - Outside temperature display [76](#)
- P**
- Paint blemishes [133](#)
 - Paint, care [133](#)
 - Paintwork, minor repairs [134](#)
 - Paintwork, waxing [134](#)
 - Park Distance Control (PDC) [78](#)
 - Parking brake [63](#)
 - Parking help [78](#)
 - Parking lamps [83](#)
 - Parking, winter [111](#)
 - PDC (Park Distance Control) [78](#)
 - Performance [172](#)
 - Pocket flashlight [92](#)
 - Pollen [90](#)
 - Power seat [49](#)
 - Power steering [111](#)
 - Power windows [44](#)
 - safety switch [45](#)
 - Pressure monitoring, tires [80](#), [167](#)
 - Pressure, tires [27](#), [113](#)
- R**
- Radiator [175](#)
 - Radio
 - refer to the separate Owner's Manual
 - Radio Data System (RDS) [164](#)
 - Radio reception [112](#), [164](#)
 - Rain sensor [69](#), [166](#)
 - RDC (Tire Pressure Control) [80](#), [167](#)
 - RDS (Radio Data System) [164](#)
 - Reading lamps [84](#)
 - Rear backrest, folding [97](#)
 - Rear lamps [145](#)
 - Rear window
 - defroster [70](#), [90](#)
 - Rearview mirror [52](#)
 - Reclining seat [47](#)
 - Refueling [26](#)
 - Remote control [35](#)
 - Removing condensation, windows [89](#)
 - Replacement key [32](#)
 - Reporting safety defects [7](#)
 - Restraint system [59](#)
 - Reverse [17](#), [64](#)
 - Roller blind, sun protection [91](#)
 - Roller sun blind [91](#)
 - Roof load capacity [174](#)
 - Roof-mounted luggage rack [100](#)
 - Rubber parts [110](#)
- S**
- Safety belt tensioner [164](#)
 - Safety belts [54](#)
 - height adjustment [54](#)
 - Safety feature [44](#)
 - Safety lock buttons [38](#)
 - Seat
 - mechanical [47](#)
 - power [49](#)
 - Seat adjustment [47](#)
 - Seat heating [91](#)
 - Seat memory [50](#)
 - Securing cargo [99](#)
 - Securing loads [99](#)
 - Selector lever, automatic transmission [65](#)
 - Self-defrosting mirrors [52](#)
 - Self-diagnostics [168](#)
 - Service and Warranty Information Booklet [131](#)
 - Service Interval
 - Display [74](#), [131](#)
 - Shiftlock [65](#)
 - Side airbags [56](#)
 - Side impact Head Protection System [56](#)
 - Side lamps [82](#)
 - bulb replacement [144](#)
 - Ski bag [98](#)
 - Skid control [111](#)
 - Sliding/Tilt sunroof [45](#)
 - closing following an electrical malfunction [156](#)
 - convenience operation [34](#)
 - Slippery roads [110](#)
 - Snow chains [110](#), [118](#)
 - Space-saver spare tire [149](#)
 - Spare key [32](#)
 - Spare tire [149](#)
 - Spare wheel [149](#)
 - Spark plugs [176](#)
 - Speaker [95](#)
 - Speed control [71](#)

Everything from A to Z

Speed display 18
Speedometer 18
Sports Seat 49
Starting 61
Starting assistance 157
Starting problems 105, 157
Starting the engine 61
Steel wheels 118
Steering 111
Steering wheel lock 61
Steptronic 65
Stopping the vehicle 62
Storage compartments 93
Storing the vehicle 137
Stroke 172
Summer tires 116
Sun visors 52
Switching off the engine 62
Symbols 4, 153
Synthetic oils 126

T

Tachometer 73
Tail lamp assembly
 bulb replacement 145
Tail lamps 145
Tank capacity 175
Technical data 172
Technical
 modifications 6, 138

Telephone
 refer to the separate
 Owner's Manual
Telephone hookup 95
Temperature adjustment 88
Temperature display
 outside temperature 76
Temperature gauge
 engine coolant 74
Temperature layering 90
Third brake lamp 147
Through-loading system 97
Tilt alarm 36, 43
 remote control 36
Tire codes 116
Tire damage 113
Tire inflation
 pressure 27, 113
Tire pressure
 checking 27
Tire Pressure Control
 (RDC) 80, 167
Tire pressure
 monitoring 80, 167
Tire replacement 114, 115
Tire specifications 118
Tire tread 113
Tools 142
Torque 172
Tow fittings 158
Tow starting 158

Towing 158
Track 173
Traction Control System
 refer to DSC 79
Transmission 64
Tread depth, tires 113
Trip odometer 73
Trunk 39
Trunk lid, refer to luggage
 compartment lid 39
Turn signal
 indicator 23, 68, 144
 bulb replacement 144
Turning radius 173
Two-way radios 112

U

Used batteries 154

V

Vacuum cleaner,
 connecting 96
Vanity mirror 52
 bulb replacement 148
Vehicle battery 152, 176
Vehicle care
 exterior 133
 interior 134
Vehicle identification 130
Vehicle Identification
 Number (VIN) 130

Vehicle immobilizer 33
Vehicle painting 133
Vehicle storage 137
Vehicle weight 174
Ventilation 86
 draft-free 90
Vinyl care 135

W

Warning lamp "Please fasten
 safety belts" 21
Warning lamps 20
Warning messages 75
Warranty and Service Guide
 Booklet 131
Washer reservoir, filling 124
Washing your car 132
Water on roadways
 deep water 104
Waxing, paintwork 134
Weights 174
Wheel rims 116
Wheelbase 173
Wheels and tires 116, 118
Width 173
Windows, convenience
 operation 34
Windshield washer nozzle
 adjustment 124
Windshield washer reservoir,
 filling 124, 175

Windshield wiper [68](#)
Windshield wiper blade
 replacement [142](#)
Winter operation [110](#)
Winter tires [116](#), [117](#)
Wiper blade
 replacement [142](#)
Wiper system [68](#)
Work in the engine
 compartment [120](#)

X

Xenon lamps [143](#), [169](#)

Owner service procedures

A

- Activated-charcoal filter, changing 155
- Adding brake fluid 129
- Adding engine coolant 128
- Adding engine oil 125

B

- Backup lamps
 - bulb replacement 145
- Battery
 - add distilled water 153
 - charging 154
- Brake lamps
 - bulb replacement 145
- Brakes, brake faults 109

C

- Changing a tire 149
- Changing a wheel 149
- Check Control 75
- Checking air pressure 27
- Checking engine oil level 125
- Checking oil level 125

D

- Defrosting the windows 89
- Difficult steering 111
- Doors, emergency operation 34

E

- Electrical accessories, failure 154
- Electrical malfunction
 - fuel filler door 156
 - sliding/tilt sunroof 156
- Emergency operation
 - doors 34
 - fuel filler door 156
 - sliding/tilt sunroof 156
- Engine oil
 - add 125
 - quality 126
 - specifications 126
 - viscosity 126

F

- Failure messages 75
- Fault displays 75
- First aid 25
- First-aid kit 25
- Fittings, towing and tow-starting 158
- Flat tire 149
- Footwell lamps
 - bulb replacement 148
- Front fog lamps
 - bulb replacement 145
- Fuses, replacing 154

G

- Glove compartment lamp
 - bulb replacement 148

H

- Hazard warning flashers 25
- Hazard warning triangle 25
- Headlamp cover, care 143
- High beams
 - bulb replacement 143

I

- Indicator lamps 20
- Inflated pressure 27, 113
- Interior lamps
 - bulb replacement 147
- Interior motion sensor, switching off 43

J

- Jack 149

L

- License plate lamp
 - bulb replacement 147
- Low beams
 - bulb replacement 143
- Lug wrench 149
- Luggage compartment lamps
 - bulb replacement 148
- Luggage compartment lid, emergency release 39

M

- Maintenance 131
- Malfunction displays 75
- Microfilter, changing 155

O

- Oil
 - quality 126
 - specifications 126
 - viscosity 126
- Onboard tool kit 142

P

- Pressure, tires 27

R

- Rear lamps 145
- Releasing the fuel filler door following an electrical malfunction 156
- Releasing the hood 120
- Removing condensation from the windows 89
- Replacement key 32
- Replacing bulbs 142
- Replacing lamp bulbs 142
- Replacing windshield wiper blades 142
- Replacing wiper blades 142
- Return used batteries 154

Owner service procedures

S

- Side lamps
 - bulb replacement [144](#)
- Sliding/Tilt sunroof, closing
 - following an electrical malfunction [156](#)
- Space-saver spare tire [149](#)
- Spare key [32](#)
- Spare wheel [149](#)
- Starting problems [105](#)

T

- Tail lamp assembly
 - bulb replacement [145](#)
- Tail lamps
 - bulb replacement [145](#)
- Tilt alarm, switching off [43](#)
- Tire damage [113](#)
- Tools [142](#)
- Tow fittings [158](#)
- Tow starting [158](#)
- Towing [158](#)
- Trunk, emergency
 - release [39](#)
- Turn signal indicator
 - bulb replacement [144](#)

U

- Use of antifreeze,
 - radiator [128](#)

V

- Vanity mirror
 - bulb replacement [148](#)

W

- Warning lamps [20](#)
- Warning messages [75](#)
- Washer fluid, adding [124](#)
- Washer nozzles,
 - adjusting [124](#)
- Washer reservoir, filling [124](#)
- Windshield washer,
 - filling [124](#)
- Working in the engine
 - compartment [120](#)

Refueling

So that you will have important specifications available when you stop to refuel, we recommend that you supplement this table with data that apply to your vehicle.

Fuel

| | |
|-------------------------------|--|
| Designation | |
| AKI: minimum | |
| AKI: for rated performance | |
| AKI: for enhanced performance | |

Engine oil

| | |
|---------|--|
| Quality | |
|---------|--|

The space between the two marks on the dipstick corresponds to approx. 1.1 US quarts (1 liter).

| Tire inflation pressure | Summer | | Winter | |
|-----------------------------|--------|------|--------|------|
| | Front | Rear | Front | Rear |
| 4 persons | | | | |
| 5 persons or 4 plus luggage | | | | |

**We wish you an enjoyable
driving experience.**



The Ultimate Driving Machine