

# CarStereoHelp.com

## BMW Stereo Help


### **BMW Car Radio Connector Removal**

Guides compiled by CarStereoHelp.com and made into a pdf by me.

Sources: <http://www.carstereohelp.com/stereoremovalBmwConnecetorR.htm>



## How to remove connector from back of most BMW car stereos



### BMW Car Radio

#### How to Remove Factory Car Stereo Connector

With car stereo removed and hanging from dash, please **do not cut wires.**

This is the most common BMW connector. Instructions may not apply for all applications


1) Using a large flat head screw driver, insert into slot at top of connector housing.

1) Pry connector housing up slightly.

1) Place another tool under your screw driver to act as a lever.



1) Pry the housing up, the lever will allow you to lift the connector housing **ALL** the way up.



1) Pull to release connector from back of car stereo.



1) Pictured is connector housing all the way **up**, connector will only release from back of car stereo in this position.



1) Pictured is connector housing all the way **down**, this is the lock down position.